




TL 3000-1  
OWNER'S MANUAL  
TL 3000



# DISC RIPPER

## TL 3000 SERIES

# KRAUSE

305 SOUTH MONROE STREET / P.O. BOX 2707

HUTCHINSON, KANSAS 67504-2707

# *Congratulations*

You have just purchased a quality designed and manufactured Krause tillage tool. Advanced features have been designed into the implement for modern farming operations. As with any investment, a return is expected, and the return received from this investment will be in the form of maximum tillage performance during many years of dependable service.

In order to maintain quality performance of the new Krause implement, it is important that all of the information in the manual be reviewed and studied carefully before operation. The contents provide operating instructions, maintenance instructions, and information on how to make adjustments.

## **SAFETY ALERT SYMBOL**



**BE ALERT TO THE POSSIBILITY OF  
PERSONAL INJURY. THIS SYMBOL  
IDENTIFIES IMPORTANT SAFETY  
MESSAGES. CAREFULLY READ THE  
MESSAGE THAT FOLLOWS.**

MODEL NUMBER \_\_\_\_\_ SERIAL NUMBER \_\_\_\_\_

PURCHASE RECORD -- DATE \_\_\_\_\_

## **A note to our customers, parts managers and dealers:**

This manual has been prepared to assist you in the proper use, daily care, and operation of your new Krause equipment. It contains specific information on the many built-in features of your equipment, the accessories and options that are available, general specifications, and instructions for making minor adjustments.

Read this manual carefully before operating your Krause equipment, and keep it in a convenient location for later reference.

In order to ensure that you have the most current owner's manual available for your implement, we have added a revision code to each manual. Please note the information listed below and specify when placing service calls or ordering parts.

Manual for Model: TL 3000

This manual covers models beginning with Serial No. 1001

Owner's Manual #: TL 3000-1

Parts Manual #: TL 3000-2

Rev.:

ISSUED TO:

ISSUED BY:

\_\_\_\_\_  
*Owner's Name*

\_\_\_\_\_  
*Krause Dealer*

\_\_\_\_\_  
*Mailing Address*

\_\_\_\_\_  
*City*

\_\_\_\_\_  
*City*

\_\_\_\_\_  
*State*

\_\_\_\_\_  
*State*

\_\_\_\_\_  
*Date of Purchase*



# Warranty Policy

(Krause Serial Numbered Wholegoods purchased subsequent to 7/1/99)

Note: All warranty work must be accomplished by a Krause Corporation Authorized Service Center rated to perform maintenance on Krause Corporation Products.

## A. KRAUSE CORPORATION ("KRAUSE") LIMITED WARRANTY.

- (1) Subject to the limitations and conditions hereinafter set forth, Krause warrants, at the time of delivery by Krause to be free from (i) defects in materials or workmanship, and (ii) defects in design that in the view of the state of the art as of the date of manufacture should have been foreseen provided, however, that the defect must be discovered and reported to Krause within the periods specified as follows. For a period of one year all new serial numbered production agricultural units covered by this warranty; for a period of thirty-six (36) months the tongue weldment, center frame weldment, wing frame weldments, disc harrow gang bearings and K-Tine field cultivator shanks.
- (2) Krause does not warrant disc blades, shanks, hydraulic cylinders, accessories and other parts not manufactured by it, but supplied with or as a part of its products. Krause will, however, obtain and pass on any adjustments provided by the manufacturers of such parts under these manufacturer's warranties. Tires supplied on Krause products, will be warranted by the tire manufacturer's retail outlets.
- (3) The entire extent of Krause's liability shall be limited to that of either reimbursing Buyer for its costs of purchasing a rebuilt, over-hauled or repaired part from either Krause or a proper Krause Authorized Service Center or, at Krause's election, reimbursing buyer for its costs of having the part repaired at a proper Krause Authorized Service Center. If Krause elects not to repair the part and if neither a rebuilt, over-hauled or repaired part is, in Krause's opinion, timely available then Krause will reimburse buyer for its costs of purchasing a new part from either Krause or a proper Krause Authorized Service Center. The labor necessary to remove from the product such part or parts and to install in the product such part or parts, as well as any repair made as the result of improper installations by Krause, shall be covered by this warranty, provided the work is performed at a proper Krause Authorized Service Center.\* If return of the defective part is required, it must be returned shipping prepaid to Krause. Krause's limited warranty will apply to any part repaired or replaced by a proper Krause Authorized Service Center pursuant to Krause's Limited Warranty: however, the applicable warranty for such part repaired or replaced shall be limited to the unexpired portion of Krause's Limited Warranty described in paragraph (1) or (2) above, as applicable. In other words, the warranty period of the part repaired or replaced does not start over from the date of reinstallation.

\*[Krause Corporation will repair or replace, free of charge, any part of the product found to be defective, within the specified warranty periods, after an inspection of the part has deemed it to be defective. Inspection must be performed by an authorized agent of Krause Corporation, or returned to the Krause factory for inspection and disposition. Warranty labor will be considered during the first year of warranty only. Krause Corporation will establish and publish an hourly flat rate for shop labor and reimbursement during the first year of the warranty period. Krause Corporation does not allow credit for the cost of travel time, mileage or hauling as a warranty allowance. During the remaining second and third year, when applicable, Krause will repair or replace the defective part, without consideration of labor charges.]

- (4) Routine services (such as inspections, field settings, adjustments, etc.) and replacement of items which deteriorate from expected normal wear and tear or exposure (such as paint, tires, hoses, blades, sweeps, etc.) are not covered by this Limited Warranty. Such routine services and replacements required during the course of operation are not considered to be the result of any defect in the product.

## **B. LIMITATIONS APPLICABLE TO KRAUSE'S LIMITED WARRANTY.**

- (1) Krause will be relieved of all obligations and liability under this warranty if:
  - (i) The alleged defect in the part is due to misuse or neglect on the part of someone other than Krause;  
or
  - (ii) Krause's identification mark or name or serial number has been removed from the part in question;  
or
  - (iii) The product and/or equipment have not been maintained, operated or stored either in accordance with applicable manuals, communications or other written instructions of Krause or any manufacturer of the part involved, or in accordance with applicable regulations and advisory circulars unless buyer shows that such maintenance, operation or storage was not a contributory cause of the defect; or
  - (iv) The part in question has been modified or altered after delivery other than by the manufacturer or in accordance with a modification or alternation scheme approved in writing by the manufacturer; or
  - (v) The product is used for purposes other than conventional owner/operator usage. Usage not considered conventional owner/operator includes, but is not limited to, operation conditions that consist of rocks or other obstructions.
- (2) For the purpose of this Warranty, no part of the product or equipment will be regarded as breaching the limited warranty merely because, subsequent to its delivery, some modification or alteration becomes necessary for product improvements or in order to meet a change in the requirements of any applicable regulation.
- (3) TO THE EXTENT ALLOWED BY APPLICABLE LAW, BUYER WAIVES AS TO KRAUSE ALL OTHER WARRANTIES, WHETHER OF MERCHANTABILITY, FITNESS OR OTHERWISE, THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACT HEREOF.
- (4) TO THE EXTENT ALLOWED BY APPLICABLE LAW, THE OBLIGATIONS OF KRAUSE SET FORTH HEREIN SHALL BE THE EXCLUSIVE REMEDIES FOR ANY BREACH OF WARRANTY HEREUNDER, AND, TO THE SAME EXTENT, KRAUSE SHALL NOT BE LIABLE FOR ANY GENERAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY DAMAGES FOR DIMINUTION OF MARKET VALUE, LOSS OF USE OR LOSS OF PROFITS, OR ANY DAMAGES TO THE PRODUCT CLAIMED BY BUYER OR ANY OTHER PERSON OR ENTITY UPON THE THEORIES OF NEGLIGENCE OR STRICT LIABILITY IN TORT.
- (5) ANY ACTION BY BUYER FOR BREACH OF THIS WARRANTY BY EITHER KRAUSE OR SELLER MUST BE COMMENCED WITHIN (1) YEAR AFTER THE CAUSE OF ACTION ACCRUES.

# Establishing Customer Warranty

## Dealer's Obligation

1. It is the responsibility of the dealer to complete a **Delivery Report and Warranty Registration** form. The form should contain the model, serial number, delivery date, along with the complete dealer and customer address. This form must be signed by the dealer and customer upon physical delivery of the product to the customer. The dealer must complete the **pre-delivery check list** provided on the Delivery Report and Warranty Registration form.
2. Dealer will review the **Predelivery Check List** located in the front of the operation manual with the customer and / or operator. This should be signed by the dealer at time of delivery to the retail customer.
3. The dealer will review the **Customer Review Sheet** located at the front of the operation manual with the customer and / or operator. This should be signed by the dealer representative and the customer.
4. An authorized Krause dealer will submit **warranty claims** on behalf of the customer. All claims must be handled through the dealer. They will then be given to the Krause District Manager for inspection and approval. Warranty requests must be filed within 60 days from completion of the repair for consideration.
5. It is the dealer's responsibility to **service** the warranty on products sold through said dealership.

This warranty gives you specific rights, and you may also have other rights which vary from state to state.

# Establishing Customer Warranty

## Customer's Obligation

1. The customer is responsible for reading the operation manual supplied with each serial numbered unit. The manual describes the safe and correct operating procedures of the specific product. The operation manual will also instruct the user on recommended lubrication and maintenance of the product.
2. The customer will advise the dealer of the anticipated start date of the product so a dealer representative can be on hand to make necessary field adjustments.
3. The owner is also responsible for inspecting the product during and after use. If a part has failed or is in need of repair, it should be replaced. When continued use of the product would result in excessive wear of other components, the part should be replaced before operation is continued. Continued use of the product may void warranty on other parts damaged from this condition. The user must make the machine available to the dealer for a warranty repair.
4. It is the customer's responsibility to deliver his machine to an authorized Krause dealer for completion of a warranty repair. If the dealer agrees to make a service trip to the customer's residence, it is an agreement between the dealer and the customer. Krause will not allow warranty credit for the cost of travel, mileage, or hauling.
5. Warranty labor consideration will only be given during the first year of warranty. Any labor charge for the 2nd or 3rd year on the limited warranty will be at the customer's expense.

This warranty gives you specific rights, and you may also have other rights which vary from state to state.

# TL 3000 SERIES DISC RIPPER DEALER PREDELIVERY CHECK SHEET

TO BE CHECKED BY DEALER

CUSTOMER \_\_\_\_\_ DATE \_\_\_\_\_

ADDRESS \_\_\_\_\_

DEALER \_\_\_\_\_

ADDRESS \_\_\_\_\_

MODEL \_\_\_\_\_ SERIAL NUMBER \_\_\_\_\_

## DEALER CHECK:

1. \_\_\_ Check to see that all rocker shaft bolts are tight.
2. \_\_\_ Check to see that hydraulic cylinders are full of oil (air bled out of cylinders). Clevis pins with cotter pins should be in place and spread.
3. \_\_\_ Examine hydraulic hoses to see that they are protected from damage.
4. \_\_\_ Bolts attaching the spindle weldments to the rocker shaft should be tight. Check to see that bearings have been adjusted and greased.
5. \_\_\_ Check lug bolts and nuts holding wheels to the hub to see that they are torqued as follows:  
9/16" Wheel Bolts to 120 Ft. Lbs. (6-Bolt Wheels)  
5/8" Wheel Nuts to 145 Ft. Lbs. (8-Bolt Wheels)
6. \_\_\_ The correct size of tires should be on the implement with proper inflation:  
12.5L x 15, 12-Ply = 52 PSI  
12.5L x 15, FI = 90 PSI  
16.5L x 16, FI - 60 PSI
7. \_\_\_ Check to see that bolts attaching tongue to frame and bolts attaching hitch to tongue are in place and secured.
8. \_\_\_ Jack should be operational for support of tongue when implement is not attached to a tractor.
9. \_\_\_ All decals are in place per page P47 of this owner's manual.
10. \_\_\_ Transport Lock Valve is correctly installed and operates satisfactorily.
11. \_\_\_ Customer review sheet filled out and signed.
12. \_\_\_ Review lighting requirements. Light kits are standard.
13. \_\_\_ Check to see that Owner's Manual is in the storage canister.
14. \_\_\_ Check to see that the SMV emblem is clean and in place.

DELIVERED BY \_\_\_\_\_

DATE \_\_\_\_\_

# TL 3000 SERIES DISC RIPPER CUSTOMER REVIEW SHEET

CUSTOMER \_\_\_\_\_ DATE \_\_\_\_\_

ADDRESS \_\_\_\_\_

DEALER \_\_\_\_\_

ADDRESS \_\_\_\_\_

MODEL \_\_\_\_\_ SERIAL NUMBER \_\_\_\_\_

1. \_\_\_ Owner's manual provided.
2. \_\_\_ Warranty card filled out and mailed.
3. \_\_\_ Review safety warnings and cautions as listed in this owner's manual.
4. \_\_\_ Review recommended maximum road speed, width, and height for this implement.
5. \_\_\_ Review field operation speeds, horsepower, depth and rock conditions.
6. \_\_\_ Demonstrate the proper use of road lock.
7. \_\_\_ Explain the operation of the hydraulic depth control.
8. \_\_\_ Review limitations of additional weight and transport speed when adding attachments.
9. \_\_\_ Explain the importance of maintaining the implement through lubrication, checking that bolts are kept tight, and replacement of worn or broken parts.
10. \_\_\_ Recommend that a safety chain be used with the implement.
11. \_\_\_ Check wheel lug bolts frequently until they become set.
12. \_\_\_ Check walking beam pivot bearings frequently until they become set.
13. \_\_\_ Explain lighting requirements for your area.

DEALER \_\_\_\_\_ DATE \_\_\_\_\_


CUSTOMER \_\_\_\_\_ DATE \_\_\_\_\_

# Table of Contents

6/02

<b>WARRANTY</b>			
<b>DEALER PREDELIVERY CHECK SHEET</b>	1	CENTER ROCKER (5 & 7 RIGID)	P11
<b>CUSTOMER REVIEW SHEET</b>	2	CENTER ROCKER (7 FOLDING)	P12
<b>TABLE OF CONTENTS</b>	3	CENTER ROCKER (9 FOLDING)	P13
<b>SPECIFICATIONS</b>	4	WING ROCKER (7 FOLDING)	P14
<b>GENERAL INFORMATION DRAWING</b>	5	WING ROCKER (9 FOLDING)	P15
<b>SAFETY DECAL INFORMATION</b>	6	WALKING BEAM (5 & 7 RIGID - CENTER)	P16
<b><u>OPERATING SECTION</u></b>		WALKING BEAM (7 FOLDING - CENTER)	P17
ABOUT YOUR DISC RIPPER	O1	WALKING BEAM (9 FOLDING - CENTER)	P18
PREPARING DISC RIPPER FOR OPERATION	O1	HUB ASSEMBLY (7 FOLDING - WING)	P19
PREPARING THE TRACTOR	O1	WALKING BEAM (9 FOLDING - WING)	P20
HYDRAULIC SYSTEM	O2	WHEELS & TIRES	P21
UNDERSTANDING YOUR DISC RIPPER	O2	GANG BEAM ASSEMBLY	P23
HYDRAULIC SAFETY (READ CAREFULLY)	O2	DEPTH ADJUSTMENT - RATCHET JACK	P24
HEATING NEAR PRESSURIZED HYDRAULICS	O3	DISC GANG ASSEMBLY	P25
HITCHING AND UNHITCHING	O3	SUBSOIL SHANK ASSEMBLY - RIGID	P26
Hitching to Tractor	O4	SUBSOIL SHANK ASSEMBLY - SPRING	P27
Unhitching from the Tractor	O4	HYDRAULICS - DEPTH 5 & 7 RIGID	P29
TRANSPORTING	O5	HYDRAULICS - DEPTH 7 & 9 FOLDING	P31
Transport Lock Valves	O5	HYDRAULICS - WING FOLD 7 & 9 FOLDING	P33
Raising The Wings	O5	HYDRAULICS - DISC GANG 5 & 7 RIGID	P35
Lowering The Wings	O5	HYDRAULICS - DISC GANG 7 & 9 FOLDING	P37
Transport Safety	O5	HYDRAULIC HOSE W/ PLASTIC GRIP ASSM.	P38
FIELD ADJUSTMENTS	O6	HYDRAULIC CYLINDER - 3-3/4 X 8	P39
Front to Rear Leveling	O6	HYDRAULIC CYLINDER - 4 X 8	P40
Side To Side Leveling	O7	HYDRAULIC CYLINDER - 4-1/4 X 8	P41
Hydraulic Depth Control Adjustment	O7	HYDRAULIC CYLINDER - 4-1/2 X 8	P42
Flexibility	O7	HYDRAULIC CYLINDER - 3-3/4 X 16	P43
DISC GANG ANGLE ADJUSTMENTS	O8	HYDRAULIC CYLINDER - 4 X 16	P44
DISC GANG DEPTH ADJUSTMENT	O8	HYDRAULIC CYLINDER - 5 X 32	P45
Rigid Scraper Adjustment	O8	CABLE GUIDE ASSEMBLY	P46
Turning in the Field	O8	DECALS & REFLECTORS	P47
SUBSOIL SHANKS	O9	LIGHT KIT	P48
SERVICING	O9		
General Maintenance	O9	<b><u>ASSEMBLY SECTION</u></b>	
Disc Gangs	O9	GENERAL ASSEMBLY INFORMATION	A2
Lubrication	O10	CENTER FRAME AND ROCKER ASSEMBLY	A2
Wheel Bearings	O10	WING ASSEMBLY (7 & 9 SHANK FOLDING)	A5
Walking Beams	O11	WING ROCKERS (7 & 9 SHANK FOLDING)	A6
GENERAL INFORMATION	O11	HYDRAULIC ASSEMBLY	A7
STORAGE SUGGESTIONS	O11	CHARGING THE CYLINDERS	A9
Repair Parts	O11	DISC GANG ASSEMBLY	A10
TROUBLESHOOTING SECTION	O12-14	SUBSOIL SHANK ASSEMBLY	A12
PROCEDURE FOR LOCATING HYD. LEAKS	O15-17	LIGHT KIT	A12
<b><u>PARTS SECTION</u></b>		DECALS	A13
CENTER FRAME (5 & 7 RIGID)	P1	PLACEMENT DRAWINGS:	
CENTER FRAME (7 & 9 FOLDING)	P3	TL 3000 5 SHANK RIGID	A14
TONGUE	P5	TL 3000 7 SHANK RIGID	A15
CUSHION TONGUE (OPTION)	P7	TL 3000 7 SHANK FOLDING	A16
DEPTH LINKAGE ASSEMBLY	P9	TL 3000 9 SHANK FOLDING	A17
DECAL & SMV MOUNT	P10		

# TL 3000 DISC RIPPER SPECIFICATIONS



M4881-76

## TL 3000 DISC RIPPER

7/02

MODEL	SHANK SPACING 30"	★ SHANK CLEARANCE	FRAME TYPE	WORKING WIDTH	TRANSPORT	
					WIDTH	HEIGHT
5 SHANK	30"	40"	RIGID	12' 6"	15' 0"	6' 5"
7 SHANK	30"	40"	RIGID	17' 6"	20' 4"	6' 5"
7 SHANK	30"	40"	FOLDING	17' 6"	13' 9"	12' 3"
9 SHANK	30"	40"	FOLDING	22' 6"	13' 9"	14' 5"

★ VERTICAL DISTANCE FROM POINT TO BOTTOM SIDE OF FRAME.

# GENERAL INFORMATION

FRAME MUST BE LEVEL FROM FRONT TO BACK DURING THE PLOWING OPERATION. FRAME MAY NOT BE LEVEL IN THE RAISED POSITION. ESTABLISH PLOW DEPTH, THEN ADJUST THE TURNBUCKLE TO OBTAIN FRONT-TO-REAR LEVELING.

CONTINUALLY CHECK WHEEL BOLTS AND TORQUE FROM 90 TO 95 FT. LBS. UNTIL FIRMLY SEATED.



ALWAYS PIN THE TRACTOR DRAWBAR BEFORE TRANSPORTING. USE A SAFETY CHAIN WITH THE TENSILE STRENGTH EQUAL TO THE GROSS WEIGHT OF THE LOAD BEING TOWED.

ROAD AT A REASONABLE SPEED. DO NOT EXCEED 15 M.P.H. OPERATING SPEEDS SHOULD NOT EXCEED 6-1/2 M.P.H.



GREASE EVERY 24 HOURS OF USE.




## WARNING


Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic lines. Tighten all connections before applying pressure.

Search for possible leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.



CHECK SHANKS AND MOUNTING BOLTS EVERY 1/2 DAY OF OPERATION




M4881-104

# SAFETY DECALS

**⚠ WARNING**

Escaping fluid under pressure can penetrate the skin causing serious injury or death. Relieve pressure before disconnecting hydraulic lines, tighten all connections before applying pressure, and inspect all lines before each use. See "Safety" section in operation manual for additional information.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.



205-8735 74-276

**⚠ WARNING**

**DO NOT OPERATE OR WORK ON THIS MACHINE UNLESS YOU HAVE READ AND UNDERSTAND THE INSTRUCTIONS AND WARNINGS IN THE OPERATION AND MAINTENANCE MANUALS.**


**FAILURE TO FOLLOW THE INSTRUCTIONS OR HEED THE WARNINGS COULD RESULT IN INJURY OR DEATH. CONTACT YOUR DEALER FOR REPLACEMENT MANUALS.**

**PROPER CARE IS YOUR RESPONSIBILITY.**

205-8740 74-570


**⚠ WARNING**

**TO AVOID INJURY DUE TO ACCIDENTAL LOWERING OF IMPLEMENT, MOVE LEVER TO LOCKED POSITION BEFORE TRANSPORTING OR SERVICING IMPLEMENT.**



205-8738 74-485

**⚠ WARNING**



**CONTACT WITH A POWER LINE OR OTHER OBSTRUCTION CAN CAUSE DAMAGE, SERIOUS BODILY INJURY OR DEATH.**

**Be aware of implement transport width and height.**

Rear attachments will add to transport height, and transport width on some implements. See Operation Manual.


205-8734 74-121

**⚠ WARNING**

**AIR TRAPPED INSIDE HYDRAULIC CYLINDERS CAN ALLOW IMPLEMENT OR WINGS TO FALL AND CAUSE SERIOUS BODILY INJURY OR DEATH.**

Purge air from hydraulic system by following detailed steps in the Operation Manual.

205-0923 74-113




74-575 RED REFLECTIVE TAPE

**NOTICE**

**MAINTENANCE LOCK**

See Operation Manual for instructions.

205-8737 74-387



74-576 ORANGE FLUORESCENT TAPE

**NOTICE**


Check wheel bolts frequently during initial transport and operation.

**Torque Wheel Nuts (5/8") to: 145 FT. LBS.**

**Torque Wheel bolts (9/16") to: 120 FT. LBS.**

See Operation Manual for proper tire inflation pressure.

202-4351 74-109



74-577 YELLOW REFLECTIVE TAPE

**⚠ WARNING**



**FAILURE OF HYDRAULIC COMPONENTS OR ACCIDENTAL OPERATION OF HYDRAULIC CONTROLS CAN ALLOW IMPLEMENT OR WINGS TO FALL AND CAUSE SERIOUS BODILY INJURY OR DEATH!**

1. Install all maintenance locks when working on or under implement. See operation manual.
2. Keep everyone clear when raising or lowering implement. Check for adequate overhead and side to side clearance before raising or lowering wings. Make certain all hydraulic systems are full of oil and free of air before raising or lowering wings or implement. Check operation manual for detailed instructions.

205-8731 74-102

See page P47 in this manual for proper location on implement.


# **OPERATING SECTION**

# SAFETY ALERT SYMBOL




BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY.  
THIS SYMBOL IDENTIFIES IMPORTANT SAFETY MESSAGES.  
CAREFULLY READ THE MESSAGE THAT FOLLOWS.


## TEN MOST COMMON HAND SIGNALS USED IN THE FIELD




**START  
THE  
ENGINE**




**MOVE OUT  
OR  
TAKE OFF**




**MOVE  
TOWARD  
ME**



**SPEED  
IT UP**



**SLOW IT  
DOWN**




**THIS FAR  
TO GO**




**STOP**



**RAISE  
THE  
EQUIPMENT**



**LOWER  
THE  
EQUIPMENT**



**STOP  
THE  
ENGINE**

# OPERATING INSTRUCTIONS

Elimination of the hazards listed in this manual should not be construed as providing guarantees that the equipment will meet or exceed all standards or regulations, or will be completely safe to all personnel. The operator should inspect and review the implement after it is in his possession.



**READ ALL OF THE SAFETY DECALS ON THE DISC RIPPER AND REVIEW THE SAFETY FIRST SUGGESTIONS ON THE BACK COVER OF THIS MANUAL TO REFRESH YOUR MEMORY. WATCH FOR THE SAFETY SYMBOL AND READ THE INFORMATION. THIS IS FOR YOUR OWN SAFETY.**

## **ABOUT YOUR DISC RIPPER**

This DISC RIPPER was designed for deep fallow tillage or stubble-mulch tillage. Your disc ripper will operate over a wide range of speeds, ranging from 3 to 6-1/2 miles per hour. Exercise caution in rocky or extremely hard conditions. If rocky conditions exist in your fields, operate at a slow speed and equip your DISC RIPPER with spring shanks.

Horsepower requirements generally will range from 35 to 50 HP per shank (do not exceed 50 HP per shank.)

Adding attachments should be limited to Krause original equipment options or attachments that weigh no more than 90 pounds per foot of cut.

## **PREPARING THE DISC RIPPER FOR OPERATION**

1. Check that the transport lock valve is closed, the tongue jack is supporting the tongue, and the hydraulic cylinders are pinned and full of oil.
2. Check for loose bolts and tighten if needed. Check again for loose bolts after the first half day of operation.
3. Check the tire pressure and correct if necessary. Inflate 8-ply tires to 45 PSI.



**Caution: Frequently check to see that wheel lug bolts are torqued to proper tightness (6-Bolt wheels to 120 Ft./Lbs.; 8-Bolt wheels to 145 Ft./Lbs.), particularly during the initial transporting and operation of the tillage tool. The bolts may work loose resulting in the loss of a wheel and subsequent loss of control of the tool and / or tractor.**

4. Make sure that all grease zerk locations have been sufficiently greased. Grease zerks will be found on the rocker shaft pivots, disc bearings, walking beams and wheel hubs. **USE EXTREME CAUTION WHEN WORKING AROUND SHARP DISC RIPPER POINTS, AND DISC BLADES.**
5. Check and adjust tightness of wheel bearings and walking beam bearings before operation, after the first week, and periodically thereafter. (See Service Section of this book)

## **PREPARING THE TRACTOR**

Read your tractor owner's manual. It will describe safe methods of operation. Make sure your tractor has proper added ballast, and that its hydraulic system is full of oil and working properly. Check tractor brakes and warning lights, make sure they are in working order.

## **HYDRAULIC SYSTEM**

Inspect the hydraulic system for tell-tale leaks and loose fittings. Tighten if needed. If you are plumbing the implement with JIC/O-Ring fittings it is not necessary to use a tape type or liquid sealer. **MAKE SURE THE RESTRICTORS ARE IN THE ROD END PORTS OF THE WING LIFT CYLINDERS.** If not previously filled, 5 & 7 Rigid Shank Models will require 7 Quarts / 6.6 Liters of your tractor manufacturer's recommended oil; 7 & 9 Shank Folding Models will require 43 Quarts / 40.7 Liters. Read the "HYDRAULIC SAFETY" section below before filling the system.



**Caution: Air in hydraulic system could allow disc ripper or wings to drop suddenly.**

**Do not operate the wing hydraulics until you have read wing lift and lock operating instructions under "TRANSPORTING".**

## **UNDERSTANDING YOUR DISC RIPPER**

The TL 3000 Series 7 & 9 Shank Disc Ripper uses a master and slave system for depth control.

As oil is pumped into the base of the master cylinder, oil is forced out of the rod end and into the base end of its slave cylinder. In turn, this forces oil out of the slave cylinder which then returns to the tractor hydraulic reservoir.

Since there is a smaller volume of oil which passes from the rod end of the master cylinder to the base end of each slave cylinder, the cylinders must be progressively smaller in diameter. The 7 and 9 Shank Folding Models use depth control master cylinders which are 4-1/2" Diameter; the wing slaves are 4" in diameter. All of the rocker cylinders have a 16" stroke length.

When the disc ripper is raised completely out of the ground, these specially designed cylinders are synchronized for uniform lifting by holding the tractor remote hydraulic control lever in the raise position for a few seconds. This allows a small volume of oil to bypass from the base of the master cylinder to the base end of the slave cylinder, and back to the tractor. Consequently, all of the cylinders are fully extended simultaneously. To maintain a precise working depth, it may be necessary to synchronize the slave cylinders once or twice during each hour of use. This can be easily done when the unit is being raised to make a turn. The disc gang cylinders are synchronized by fully raising the gangs and holding the lever.

When working with this kind of arrangement, be sure all of the cylinders are mounted in proper sequence. Hoses must be attached in the proper order, and all air bled from the hoses and the cylinders.

**REPAIR OF HYDRAULIC CYLINDERS SHOULD BE MADE BY AN AUTHORIZED KRAUSE DEALER ONLY.**

**HYDRAULIC HOSE AND CYLINDER DRAWINGS CAN BE FOUND ON PAGES P26 THROUGH P43 OF THE PARTS SECTION IN THIS MANUAL.**

## **HYDRAULIC SAFETY (PLEASE READ CAREFULLY)**

If the implement hydraulic system has never been used, stored over a period of time or disassembled for any reason, unpin the rod ends of the cylinders and support the cylinders so the rod ends will clear frame members when fully extended. Back the tractor to the front of the implement and connect the hydraulic hoses. Check the tractor hydraulic reservoir and make sure it is full of the manufacturer's recommended oil. If you are sure the implement hydraulic hose connections are tight, begin filling the system by extending and retracting the cylinders. Hold the control lever open and pause at the end of each stroke to bleed the air from the system. Continue the cycles until the cylinders respond with immediate solid actuation. When you are sure the systems are free of air, pin the rod ends of the cylinders to the implement cylinder lugs.



**Warning:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.

**AVOID HEATING NEAR PRESSURIZED HYDRAULIC HOSES**

Flammable spray can be generated by heating near pressurized hydraulic hoses, resulting in severe burns to yourself and bystanders. Do not heat by welding, or using a torch near hoses. Hose can be accidentally cut when heat goes beyond the immediate flame area.


**THE FOLLOWING WARNINGS PERTAIN TO THE MORE COMMON ABUSES OF HYDRAULIC HOSE:**

1. **INSPECT** the hose assembly before each use.
2. **REPLACE** the hose assembly immediately if:
  - A. The jacket of the hose appears abnormal.
  - B. You have reason to believe it may be abnormal.
  - C. There is any fluid leakage.
  - D. The couplings are damaged.
  - E. The hose is damaged or kinked.
  - F. The reinforcement is visible through the jacket.
3. **DO NOT EXCEED** the maximum recommended working pressure of the hose.
4. **DO NOT KINK** the hose assembly.
5. **DO NOT BEND** the hose assembly beyond its minimum bend radius of 3.25 inches.
6. **DO NOT EXPOSE** to temperatures in excess of 225° Fahrenheit.
7. **DO NOT USE AS A STRENGTH MEMBER** for pulling or lifting equipment.

**Caution:** If replacing hydraulic hose, use only hose that meets or exceeds 3,000 PSI working pressure.

IMPORTANT: REPAIR OF HYDRAULIC CYLINDERS SHOULD BE MADE BY AN AUTHORIZED KRAUSE DEALER.

Prevent damage to trail hoses by supporting them from the tractor with an elastic strap "A". Avoid having excess hose between the implement support "B" and the tractor connection "C". Either reposition the hose farther back on the implement or request a shorter hose from your dealer.



**Caution:** Air in the hydraulic system will allow DISC RIPPER to drop suddenly.

**HITCHING AND UNHITCHING**


**Caution:** Do not allow any person to stand between the tractor and the implement while backing into position. Sudden loss of control could cause serious injury or death to a person caught between the tractor and implement. Tell your helper to wait until you give him the signal that the tractor is in park or neutral and the hand brake is set and engine is shut off.

**Note:** Hydraulic hose grips are color coded as shown below.


<b>Black / Black</b> . . . . . Lower Unit	<b>Red / Black</b> . . . . . Raise Unit
<b>Yellow / Yellow</b> . . . . Lower Wings	<b>Red / Yellow</b> . . . . . Raise Wings
<b>Gray / Gray</b> . . . . . Lower Front Disc Gangs	<b>Red / Gray</b> . . . . . Raise Front Disc Gangs
<b>Blue / Blue</b> . . . . . Lower Rear Disc Gangs	<b>Red / Blue</b> . . . . . Raise Rear Disc Gangs

## HITCHING TO TRACTOR

- A. The implement must be in a raised position and the transport lock valve in place before hitching to the tractor.
- B. Unpin the tractor drawbar so it can be moved from side to side.
- C. Back the tractor to the implement.
- D. Attach the clevis<sup>①</sup> to the tractor drawbar<sup>②</sup> with clevis pin<sup>③</sup> that fits the hole size in the tractor drawbar. Make sure pin is locked or bolted<sup>④</sup> in place to prevent loss.
- E. Connect hydraulic hoses to the tractor.
- F. Place tongue jack in storage position.
- G. Attach the safety chain. See page O5.



**IMPORTANT:** BEFORE MOVING THE IMPLEMENT BE SURE THAT THE LOWER ARMS OF THE THREE POINT HITCH HAVE BEEN RAISED TO THE TOP AND SECURED TO PREVENT DAMAGE TO THE CLEVIS AND TONGUE WHEN MAKING TURNS.



## UNHITCHING FROM THE TRACTOR

If the implement is not to be used for the remainder of the day, select a good parking place that will permit the lowering of the wings (7 and 9 Shank Folding Models ONLY). The implement should be parked in the storage position with the transport lock valve closed. If the implement is to remain parked for storage over a long period of time, be sure to read the storage suggestions listed on page O11.

1. To unhitch the implement from the tractor, place the tractor in park or neutral and set the hand brake. If you are not parking on level ground, block the implement tires to prevent damage to the jack.
2. Close Transport Lock Valve, turn off the tractor power and relieve any pressure that might be in the implement hydraulic system by moving the tractor control lever back and forth.
3. Using the tongue jack, raise the tongue height until the clevis pin can be removed.

**NOTE:** If rear attachments have been added, and the implement is tail-heavy, lower the unit close to the ground before closing transport lock valve. This will transfer weight to the tongue.

4. Disconnect the hydraulic hoses, and the tractor may be moved away.



**Warning:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.


**Caution:** Do not stand on or straddle the tongue when unhitching. If rear attachments have been added to the rear of the implement, it may affect the balance of the implement, causing the tongue to raise up suddenly when unhitching.

## TRANSPORTING

**⚠ Caution:** Always close **both** transport lock valves when transporting to prevent unit from falling due to hydraulic failure, or accidental activation of the operator's control. Lowering of the tool during transport could result in loss of control of implement and/or tractor. The tractor drawbar must always be pinned for transport.

### TRANSPORT LOCK VALVES

The road locks are hydraulic valves. Turning the handle to release the poppet (handle towards the tractor) will close the valve. Turning the handle to engage the poppet (handle towards the implement) will open the road lock for field use. **NOTE:** The road lock will allow the unit to be raised when in the transport position, but will not allow the unit to be lowered.




M4881-97

### RAISING THE WINGS

The implement should be in the raised position with the transport lock valve closed. If the system is full of oil, you are ready to raise the wings. The wings will be secured in the raised position with a transport lock valve.

**⚠ Warning:** Always stand clear of wings when they are in the raised position. A hydraulic failure or activation of hydraulic controls by someone could result in serious injury to anyone under the wings.

MOVE VALVE HANDLE TO CLOSED (LOCKED POSITION) BEFORE TRANSPORTING IMPLEMENT



M4881-96


### LOWERING THE WINGS

Open the wing lock valve to unlock both wings then lower the wings with all persons standing at a safe distance away from the implement.

### TRANSPORT SAFETY

**⚠ Warning:** Always use a safety chain with tensile strength equal to the gross weight of the implement, plus any attachments, when transporting.


**NOTE:** A safety chain, SMV emblem, and a light kit were furnished as standard equipment with your implement. Make sure they are in place, clean and in working order.



M4881-98

Insert the ASAE Slow-Moving-Vehicle (SMV) emblem into the bracket provided. The emblem is to be mounted point up, in a plane perpendicular to the direction of travel  $\pm 10^\circ$ . It shall be placed centrally at the rear of the vehicle unobscured, and 2' to 6' (0.61 to 1.8m) above the ground, measured from the lower edge of the emblem. The SMV emblem should be wiped clean before entering the road or highway.

Comply with state and local laws pertaining to lighting and road widths. Turn on flashing lights whenever traveling on a highway except where it is prohibited by law. If the implement obscures the tractor warning lamp, a lamp must be added to the left of the implement. Transport during daylight hours only. Watch your clearance. Be aware of obstacles on the side of the road that might be caught by the implement when passing by. Pull over to the side of the road to permit safe clearance for oncoming traffic and passing vehicles. Keep the red, orange and yellow reflectors clean and visible. Replace reflectors if they become faded or damaged. Watch for pedestrians on the side of the road that need to be warned of your presence.



**⚠ Caution:** Always check the conditions of transport lock valves, tires, wheels, hubs, safety chain, hitch bolts, and clevis pin before transporting the implement.

Check specification page and be aware of the transport height and width of your implement.

**⚠ Danger:** Do not exceed 15 m.p.h. in transport on best surface. Exceeding this speed can result in failure in wheel hubs or spindles and loss of control of implement and/or tractor. Do not tow this implement if its weight exceeds 1-1/2 times the weight of the towing unit. Pin tractor drawbar to prevent side sway during transport.

## **FIELD ADJUSTMENTS**


THERE ARE (3) IMPORTANT RULES TO FOLLOW FOR PROPER FIELD ADJUSTMENT:


1. LEVEL THE IMPLEMENT FROM FRONT TO REAR.
2. LEVEL THE IMPLEMENT FROM SIDE TO SIDE.
3. SET THE HYDRAULIC STOP ON THE CYLINDER, AND CARRY SOME OF THE WEIGHT OF THE IMPLEMENT ON THE WHEELS.

A level implement in the working position will give the most uniform penetration and field leveling possible. Leveling the implement for the first time should be performed on as level of a surface as is possible. Hitch the tractor to the clevis and lower the wings and extend the wing lift cylinders to the maximum stroke.

### **FRONT TO REAR LEVELING**

With the implement close to the ground, turn the turnbuckle until the frame is level front-to-rear. NOTE: Turn clockwise to lower the front, and counter-clockwise to raise the front. This is an average position and should be readjusted at field depth. The angle of the front frame members can give the illusion that the front is running deeper than the back. When checking the front to rear leveling in the field, always stand well away from the unit and view the frames from frame height.





M3990-33


## SIDE TO SIDE LEVELING

If the wing is too high, loosen the outside NUT A, and thread down NUT B until the wing is level with the center section, and then re-tighten NUT A. (See photograph to the left.)

## HYDRAULIC DEPTH CONTROL ADJUSTMENT

The STOP VALVE controls the unit depth. when a depth change is required, turn the knob to move the striker closer to the valve to decrease depth or further away from the valve to increase depth.

If the unit depth varies during field operation, see the "Problem Solving" section in this manual.





M4881-103

## FLEXIBILITY

**ALWAYS WORK WITH WINGS DOWN:** Major damage may occur to disc blades if used with the wings up. For maximum flexibility, make sure the wing hydraulic cylinders are fully extended after the wing is down.

When working terraced ground, place the wing up on the terrace, not down over the terrace, as the wings are limited in their downward movement, but not in the upward movement.




## DISC GANG ANGLE ADJUSTMENTS

The rear disc gangs can be set at a 10°, 15° or 20° angle.

Use the maximum angle to move more soil and to bury more residue.

Use the minimum angle in wet conditions or when more surface residue is desired. To change the angle of the disc gangs:

1. Use the tie rod wrench to loosen the 1-1/2NC Slotted Hex Nut.
2. Insert handle of the tie rod wrench into socket and remove clevis pin.
3. Move gang to desired position and insert clevis pin.
4. Tighten the 1-1/2NC Slotted Hex Nut and secure with PTO Pin.



## DISC GANG DEPTH ADJUSTMENT

The depth of the front and rear disc gangs are controlled by hydraulic cylinders. Do not set the blades deeper than the depth required to slice the crop residue. Caution must be used to prevent excessive loading of the disc gangs. This will cause the unit to have erratic depth, not remain level, and limit its ability to absorb shock loads when striking rocks or stumps.

## RIGID SCRAPER ADJUSTMENT

- A. Scrapers can be adjusted by moving the entire assembly from side to side at the bracket locations.
- B. Also, each scraper blade can be adjusted individually along its mounting frame.


When scrapers are required, adjust blades so that the scraping edge of each scraper blade is flush against the disc blade, but not tight enough to prevent the gang from revolving freely. When the scrapers are not required, adjust the scraper frame to move the scraper blades away from the disc blades. Under most conditions, scrapers should be positioned approximately 1/8" from the surface of the disc blades.

Each field may require some individual scraper adjustment. Moving scrapers one way or the other will help solve your individual scraper problems. Frequent examination will prevent damage to scraper assemblies and spacer spools.

## TURNING IN THE FIELD

Short turns at working depth may result in driving the outside disc blades deeper into the ground, causing damage to disc blades or bearings. If short turns must be executed, raise the implement out of the ground and complete the turn before engaging the tool for further tilling.

When lifting the implement completely out of the ground, hold the tractor hydraulic valve open for a second or two to resynchronize the slave cylinders.




**IMPORTANT:** 4-WHEEL DRIVE TRACTORS CAUSE SEVERE SIDE STRAIN ON TONGUE AND CLEVIS UNLESS THE DRAWBAR IS ALLOWED SOME FREEDOM TO SWING DURING FIELD OPERATION. DRAWBAR MUST BE PINNED FOR TRANSPORT.

## **SUBSOIL SHANKS**

Inspect shanks daily for loose bolts and excessive wear on ground engaging components and the trip mechanism.

**⚠ Warning:** **DO NOT ATTEMPT TO DISASSEMBLE THE SPRING ASSEMBLY. THE SPRING IS PRE-LOADED INTO THIS POSITION AND WILL REACT VIOLENTLY IF RELEASED. SERIOUS BODILY INJURY OR DEATH COULD RESULT.**  
**NO individual repair parts are available for the spring assembly.**



## **SERVICING**


### **GENERAL MAINTENANCE**

All bolts should be checked and tightened after the first half day's operation and periodically thereafter.

### **DISC GANGS**


Before attempting to work on the disc gang components, assemble maintenance locks (4830-117-0) on each of the two center rocker cylinder rods, block the tires, and close the transport lock valve.

NOTE: 5 & 7 Shank Rigid Models: Attach the maintenance locks to the depth control link for storage when not in use (see illustration on page P8). 7& 9 Shank Folding Models: Attach the maintenance locks to the wing stop weldments for storage (see illustration on page P2).




M4881-75

Check the disc gang tie rods frequently. To tighten, attach a 5-1/2 ft. pipe over the tie rod wrench handle. Tighten the nut to 1,200 Ft. Lbs. by applying approximately 200 lbs. of weight to the end of the pipe.



CART25




BE SURE THE BEARING ARM FITS FLAT AGAINST THE GANG BEFORE TIGHTENING THE U-BOLTS.

**⚠ Caution:** Be sure that the disc gang is locked with a tie rod wrench on the opposite end before force is applied.

**⚠ Danger:** Due to their sharpness and weight, serious injury can be inflicted by disc blades and gangs if not handled safely. Watch for unsafe conditions, Keep co-workers safety in mind. Should personal injury occur, have medical treatment administered immediately.

Use the same procedure as described when setting up a new unit. Make sure the top of the bearing arms are parallel with the bottom of the frame before tightening the U-Bolts.

## LUBRICATION



The initial lubrication of all grease fittings will assure long life and satisfactory performance from the implement. Use a multi-purpose type grease at all grease zerk locations after each 24 hours of operation. Points of lubrication are: walking tandem bearings, shanks, and wheel hubs. Disc gang bearing should be greased with a high quality multi-purpose type grease after each use and after long periods of storage. The disc bearings cannot be overgreased and should be greased until grease is visible past the seals.

## WHEEL BEARINGS

Grease wheel bearings every 24 hours of use. Check for excessive end play each time that the bearings are greased. Once a year, clean and repack the wheel bearings with EP#2 Grease. Replace seals each time that the bearings are removed. Replace any worn or damaged parts. Use light oil on the seal surface and use extreme care when pushing seal over the spindle. Install outer bearings, flat washer, and slotted nut. Tighten nut while turning hub until there is resistance to rotation. Then back off nut 1 to 2 slots until hub turns freely without end play. Secure nut with clinched cotter pin.

## WALKING BEAMS

Grease the walking beam bearing every 24 hours of use. When greasing the bearings, lower the unit onto the points and raise the walking beams off the ground. Check each walking beam for any slack in the pivot bearings. When slack is found tighten the axle nut until slack is eliminated and tighten 5 to 10 ft. lbs. of preload on the bearings. **DO NOT BACK THE AXLE NUT OFF.** Check, clean, and repack the walking beam bearings each year in a procedure that is similar to that of the wheel bearings.

## GENERAL INFORMATION

If problems are encountered in the field, and the operator requires aid or a possible remedy for the problem, a special troubleshooting section titled "Possible Remedies for Field Problems" has been added at the end of this section.

## STORAGE SUGGESTIONS

Make sure transport lock valve is in the closed position. For long term storage, coat disc blades and hydraulic cylinder rods with rust preventative. For added safety, lower the implement to the ground. Cylinder rods may also be unpinned and retracted to protect the polished rod surfaces. Inspect the implement for worn or damaged parts and replace as necessary to avoid delays the next season.

## REPAIR PARTS

Refer to the Assembly Section of this book when repairing or replacing parts, and follow the same procedure as used when assembling a new unit. Reverse this procedure for disassembly. The Parts Section of this manual will show a breakdown of assemblies, location of parts, and part numbers.

It is recommended that KRAUSE replacement parts be used. **KRAUSE PARTS WERE DEVELOPED AND TESTED FOR THESE IMPLEMENTS.**

**⚠ Caution:** If replacing hydraulic hose, use only hose that meets or exceeds 3,000 PSI working pressure.


**IMPORTANT:** REPAIR OF HYDRAULIC CYLINDERS SHOULD BE MADE BY AN AUTHORIZED KRAUSE DEALER.

## AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.

**⚠ Caution:** Explosive separation of a tire and rim parts can cause serious injury or death.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Inspect tires and wheels daily. Do not operate with low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



## SUGGESTED REMEDIES FOR POSSIBLE FIELD PROBLEMS

PROBLEM	POSSIBLE CAUSE	SUGGESTED REMEDY
Implement does not follow directly behind tractor	Points are different lengths	Replace or turn
	Bent shanks	Replace or straighten
	Bent rocker shaft	Straighten or replace
	Incorrect tire size or air pressure	All tires should have the same air pressure as reflected on page 3 Specifications Chart All tires should be within $\pm 1/2$ " diameter
	Wing Frame deeper	Adjust wings
Implement is not level from side to side	Incorrect tire size or air pressure	All tires should have the same air pressure as reflected on page 3 Specifications Chart All tires should be within $\pm 1/2$ " diameter
	Bent or twisted rocker shaft or wheel arm	Straighten or replace.
Plugging	Straw is dragging	Work deeper
		Change working angle with respect to row direction
	'Bunched' trash	Work shallow first time
	Field is too wet	Allow field to dry
	Front gangs too shallow	Increase depth
	Discs plugging	Remove scraper at bearing arm location
Implement not level from front to rear	Clevis height not adjusted when depth changed	Use wheels to gauge depth and adjust turnbuckle with unit in working position
Implement leaves excessive ridges	Frame not level	Level frame at operating depth as described in the Operating Instructions
	Bent shank	Straighten or replace
	Points with old residue will cause soil build-up and prevent necessary scouring for even flow	Remove trash and residue. Clean the disc ripper after operation. Before storing use a rust preventative.
	Rear gangs too shallow	Increase depth
Implement will not lower	Road lock	Open road lock
	Remote depth valve plumbed backwards	Check plumbing to hydraulic schematic
Wheels have excessive wobble	Loose wheel bolts	Stop. Torque wheel bolts from to proper tightness. See Dealer Check Sheet.
	Loose spindle nut	Tighten spindle nut, then turn back one notch and pin
Unit settling or continually going deeper while working <b>WARNING:</b> Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic lines. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids. If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a new hours or gangrene may result.	Hydraulic System.	Use depth valve
		Check for leaks in system
		Install new O-Ring in depth valve
		Install new cylinder seal kit
		Tractor valve is leaking
Implement will not penetrate	Ground is too hard	Wait for moisture
	Excessive field speed	Slow to 5 MPH or less
	Incorrect stroke control setting on depth cylinder	Readjust hydraulic actuator stop
	Discs set too deep	Raise gangs

**\*ATTENTION: DO NOT REMOVE SHANKS**

\* NOTE: Removing shanks to obtain additional depth will cause the remaining shanks and frame members on which these shanks are mounted, to be overloaded. This could cause bent shanks, broken bolts or clamps, or twisted frame members.

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>SUGGESTED REMEDY</b>
Leaving center ridge	Excessive speed	Reduce speed
	Rear gangs cutting too deep	Shorten turnbuckle on tongue Reduce depth of rear gangs
Leaving center furrow	Discing too slowly	Increase speed, not to exceed 6 m.p.h., 5 m.p.h. in rocky conditions
	Rear gang not cutting deep enough	Increase depth of rear gangs
Leaving untilled center strip	Discing too shallow	Increase depth
Leaving furrow on outside	Rear running too deep	Readjust turnbuckle on tongue
	Extension disc blade incorrect size	Decrease size of extension disc blade
Leaving ridge on outside	Front running too deep	Adjust turnbuckle on tongue
	Not enough overlap	Move tractor toward plowed ground
	Wing section running too deep	Adjust wing rocker shaft leveling screw
	Excessive speed	Reduce speed
Center section not level from side to side	Incorrect air pressure in tires	Inflate tires to correct P.S.I. see Dealer Check Sheet
Wing not level from side to side	Wing too high	To lower wing, shorten wing adjustment screw
	Wing too low	To raise wing, lengthen wing adjustment screw
	Wing lift cylinder not fully extended	Extend cylinder to maximum length and hold open briefly
	Slave cylinders out of phase	Raise unit out of ground and hold control lever open until all cylinder are completely extended
Implement not level front to rear during field operation	Tongue turnbuckle	Lengthen turnbuckle to raise front; Shorten turnbuckle to lower front
Gangs plugging	Extremely wet conditions	Decrease depth of work or allow field to dry if possible
	Worn or improper adjustment of scraper blades	Readjust scrapers, replace worn parts

<b>PROBLEM</b>	<b>POSSIBLE CAUSE</b>	<b>SUGGESTED REMEDY</b>
Gang does not revolve	Obstruction in disc gang	Check for rocks, mud, roots, etc.
	Scrapers	Check for scrapers adjusted too tight to the disc blades
	Seized bearing	Replace
	Plugging at bearing arm	Try removing scraper at this location
Wing will not flex down far enough	Wing lift cylinder	Make sure cylinders are fully extended
Disc will not penetrate or penetrates too much	Stroke control settings on wheel control cylinders	Readjust depth control striker
Wheels have excessive wobble	Loose wheel bolts	See Dealer Check sheet for proper torque values.
	Loose spindle nut	Tighten nut until tight, then turn back one notch and pin
Discs have excessive wobble	Tie rod nut too loose	Retorque nut on tie rod to 1,200 Ft. Lbs.
Disc will not lower or wings will not lower	Transport locks engaged	Open transport lock valves
Wings will not raise to transport position	Plugged restrictor	Remove restrictors from ends of cylinder and check orifice for foreign material
	Insufficient hydraulic pressure	Check tractor hydraulic system
Inadequate transport clearance	Wheel control cylinders not extended	Extend cylinders
	Tire pressure low	Inflate tires to proper P.S.I. See Dealer Check Sheet
	Disc not level from front to rear	Adjust turnbuckle on tongue


# TEST PROCEDURE TO LOCATE INTERNAL LEAKING CYLINDER IN A REPHASING SYSTEM

## 7 & 9 SHANK FOLDING MODELS

1. Raise the unit until the points are 4" to 5" above the ground, but do not fully extend the cylinder.
2. Measure the length of the four rocker cylinders and record those lengths.
3. Allow the unit to sit for a period of time until there is a measurable change in one of the cylinder lengths. This may require an hour or two (preferably overnight).
4. Measure the length of each cylinder again and note whether or not the cylinder extended or retracted.
5. Match your results to one of the five case studies shown on the following pages to locate the leaking cylinder.

### CASE 1:


Symptom: Left wing lowering as the implement is pulled in the field  
Probable Cause: Left wing cylinder piston seal leak  
Test Result: (See page O15) Left wing cylinder retracts, all other cylinders do not change  
Leak Location: Left Wing Rocker Cylinder



M3990-41

**CASE 2:**


Symptom: Left wing raising as the implement is pulled in the field  
Probable Cause: Left main frame cylinder piston seal leak  
Test Result: (See page O15) Left wing cylinder extends, all other cylinders retract  
Leak Location: Left Main Frame Rocker Cylinder



M3990-42

**CASE 3:**


Symptom: Right wing lowering as the implement is pulled in field  
Probable Cause: Right wing cylinder piston seal leak  
Test Result: (See page O15) Wing cylinder retracts, all other cylinders do not change  
Leak Location: Right Wing Rocker Cylinder



M3990-43

**CASE 4:**


Symptom: Right wing raising as the implement is pulled in field  
Probable Cause: Right main frame cylinder piston seal leak  
Test Result: (See page O15) Right wing cylinder extends, all other cylinders retract  
Leak Location: Right Main Frame Rocker Cylinder



M3990-44

**CASE 5:**

Symptom: Entire implement will not maintain set depth  
Probable Cause: Depth Valve Leak  
Test Result: (See page O15) All cylinders are retractor or extending at the same time  
Leak Location: If all cylinders are extending at the same rate, the tractor valve is leaking. IF all cylinders are retracting at the same rate, the leak could be in the stroke control valve or the tractor valve.



M3990-45


**This page intentionally left blank.**

# **PARTS SECTION**

THE FOLLOWING ILLUSTRATED PARTS SECTION HAS BEEN COMPILED TO REFLECT PART NUMBERS REQUIRED TO ORDER PARTS, AND TO SUPPORT THE ASSEMBLY SECTION FOR DIMENSIONS AND DESCRIPTIONS OF ALL PARTS, BOLTS, PINS, ETC. THE OPERATOR CAN ALSO IDENTIFY PART NAMES TO CLARIFY PROPER OPERATIONAL STEPS.



# CENTER FRAME ASSEMBLY




REV. 6/02  
M48B1-38

## FOR MODELS - TL3000 5 SHANK, 7 SHANK

8/27/02

Item	Part Number	Part Description	Qty.
1	4881-5001-0A	5 & 7 Center Frame Weldment	1
2	★ 4881-7018-0	7 Shank Left Frame End Weldment	1
3	★ 4881-7020-0	7 Shank Right Frame End Weldment	1
4	62-195	3/4NC x 2-1/2" GD5 Cap Screw	8
5	64-112	3/4"STD. Lock Washer	16
6	63-112	3/4NC Hex Nut	16
7	62-222	3/4NC x 9-1/2" Machine Bolt	8
8	53-101	Wear Bushing, 1.50 od x 1.28 id x 1.00	4
9	53-110	Wear Bushing, 2.00 od x 1.81 id x 1.50	4
10	53-109	Wear Bushing, 1.50 od x 1.28 id x .50	12
11	53-102	Wear Bushing, 1.25 od x 1.02 id x 1.00	4
12	25-1163	Hose Clamp	1
13	99-218	Owner's Manual Canister (Black)	1
14	2191-35-0	Tie Rod Wrench	1
15	62-237	1NC x 3" Cap Screw	8/12
16	64-118	1" STD. Lock Washer	8/12
17	63-117	1NC Hex Nut	8/12
18	■ 4881-7070-0	Extension Weldment	2
19	65-101	1/8" STD. Zerk	2
★ 7 Shank Unit ONLY			
■ 5 Shank Unit ONLY			




# CENTER AND WING FRAMES


FOR MODELS - TL3000 7 SHANK, TL3000 9 SHANK

8/27/02

<i>Item</i>	<i>Part Number</i>	<i>Part Description</i>	<i>Qty.</i>
1	4881-9001-0A	7 & 9 Center Frame Weldment	1
2	4881-9018-0A	Left Wing Frame Weldment	1
3	4881-9020-0A	Right Wing Frame Weldment	1
4	53-118	Wear Bushing	12
5	53-101	Wear Bushing, 1.50 od x 1.28 id x 1.00	4
6	53-110	Wear Bushing, 2.00 od x 1.81 id x 1.50	8
7	53-102	Wear Bushing, 1.25 od x 1.02 id x 1.00	8
8	53-109	Wear Bushing, 1.50 od x 1.28 id x .50	16
9	5430-0-24	Hinge Lock Pin	4
10	4881-0000-2	Hinge Pin	6
11	64-145	Wear Washer, 2.50 od x 1.62 id	2
12	63-181	1-1/2NC GD5 Slotted Hex Nut	6
13	60-711	1/4"DIA. x 3" Cotter Pin	6
14	25-1163	Hose Clamp	1
15	99-218	Owner's Manual Canister (Black)	1
16	2191-35-0	Tie Rod Wrench	1
17	4881-9044-0	Wing Stop Weldment	2
18	62-424	5/8NC x 1-1/2" GD5 Cap Screw	6
19	64-109	5/8" STD. Lock Washer	4
20	63-109	5/8NC Hex Nut	4
21	61-244	U-Bolt, .50"DIA. x 6.06 W x 5.25" L	4
22	64-107	1/2" STD. Lock Washer	8
23	63-106	1/2NC Hex Nut	8
24	4881-7070-0	Extension Weldment	2/4
25	62-237	1NC x 3" Cap Screw	8/16
26	64-118	1" STD. Lock Washer	8/16
27	63-117	1NC Hex Nut	8/16
28	65-100	1/8" x 45° Zerk	10
29	4881-1070-0	1-1/4" Eyebolt	2
30	63-124	1-1/4NC Hex Jam Nut	4
31	60-613	Roll Pin, 3/8" DIA. x 1-1/2"	2
	4830-117-0	Cylinder Lock Assembly (Includes ★ Items)	
32	★ 4830-117-1	Cylinder Lock	2
33	★ 60-103	PTO Lock Pin	2
34	3131-77-0	Cylinder Clevis Pin	2
35	53-109	Wear Sleeve	4
36	64-126	1-1/4" STD. Flat Washer	2
37	60-606	1/4" DIA. x 2" Roll Pin	2
38	4881-0000-37	Bolt Plate	2
39	63-110	5/8NC Lock Nut	2








## CUSHION TONGUE ASSEMBLY (OPTIONAL)

**FOR MODELS - TL3000 5, 7, 9 SHANK**

6/02

Item	Part Number	Part Description	Qty.
1	4881-9030-0	Tongue Weldment	1
2	4885-0-4A	Tongue Pin, 1-3/4" DIA. x 9-1/2"	2
3	60-616	Roll Pin, 3/8" DIA. x 2-1/4"	10
4	4881-7071-0	Pivot Weldment	1
5	65-101	1/8" STD. Zerk	2
6	64-154	Machine Bushing, 3-1/8" O.D. x 2-1/8" I.D. x 10 Ga.	2
7	60-621	Roll Pin, 1/2" DIA. x 2-1/2"	2
8	6142-83-0	Left Hand Threaded End	1
9	4830-35-0	Turnbuckle Weldment	1
10	6142-82-0	Right Hand Threaded End	1
11	65-114	1/4" Drive Zerk	2
12	6127-0-11	Pin, 1-1/4" DIA. x 6-3/4"	2
13	53-113	Wear Sleeve	4
14	60-606	Roll Pin, 1/4" DIA. x 2"	4
15	4881-0000-4	Pin, 1-1/2" DIA. x 6-3/4"	1
16	53-166	Wear Sleeve	6
17	4881-9032-0	Swing Hitch Weldment	1
18	4881-0000-3	Hitch Pin	1
19	62-176	5/8NC x 3-1/2" GD5 Cap Screw	3
20	63-110	5/8NC Lock Nut	3
21	4881-0000-5	Pivot Pin	2
22	4881-7086-0	Hitch Shock Mount (Includes Wear Sleeves)	2
23	62-250	1NC x 6-1/2" Cap Screw	2
24	64-118	1" STD. Lock Washer	2
25	63-117	1NC Hex Nut	2
26	76-231	Urethane Spring	2
27	62-821	3/4NC x 8" GD8 Cap Screw	2
28	64-215	Special Washer	2
29	63-113	3/4NC Hex Jam Nut	2
30	62-191	3/4NC x 1-1/2" GD5 Cap Screw	1
31	64-112	3/4" STD. Lock Washer	1
32	64-147	Special Washer, 3-1/2" O.D. x 13/16" I.D. x 1/4"	1
33	72-352	20,000# Safety Chain (5 & 7 Shank Rigid Models)	
	72-356	30,000# Safety Chain (7 & 9 Shank Folding Models)	1
34	2135-54-0	Hitch Weldment	1
35	4885-0-6	Hitch Bushing	1
36	4885-0-5	Hitch Pin	1
	6200-90-0	Pin Assembly (Includes • Items)	1
37	• 6200-90-1	Pin	1
38	• 60-716	Hair Pin Cotter	1
39	4956-56-0	Jack Assembly (Includes ★ Items)	1
40	★ 73-111	Jack	1
41	★ 61-172	U-Bolt, 1/2" DIA. x 2-9/16"W x 3-3/4"L	3
42	★ 64-107	1/2" STD. Lock Washer	6
43	★ 63-106	1/2NC Hex Nut	6
44	★ 4956-55-0A	Jack Mount Weldment	1
45	★ 60-702	Cotter Pin, 3/16" DIA. x 1-1/2"	1
46	★ 60-106	Fas Pin w/ Chain	1
47	• 60-626	3/16" DIA. x 1-1/2" Roll Pin	1



# DEPTH LINKAGE ASSEMBLY


FOR MODELS - ALL

9/5/02

Item	Part Number	Part Description	Qty.
1	62-635	3/8NF x 5/8" Cap Screw	1
2	7300-83-5	Gauge Slide	1
3	7300-87-1	Threaded Rod	1
4	63-100	1/4NC Hex Nut	4
5	64-100	1/4" STD. Lock Washer	4
6	7300-83-3	Striker Spacer	4
7	62-385	1/4NC x 2-1/2" GD5 Cap Screw	4
8	7300-84-0	Striker Weldment	1
9	60-632	5/32" DIA. x 3/4" Roll Pin	1
10	76-102	Spring	1
11	99-215	Knob	1
12	64-162	1/2"SAE Flat Washer	1
13	62-636	3/8NC x 6" GD5 Cap Screw	2
14	4881-1084-0	Linkage Weldment	1
15	3112-69-1	Valve Spacer	4
16	3112-69-2	Bolt Strap	2
17			
18	25-2474	Stop Housing Assembly	1
19	63-134	3/8NC Nylon-Top Lock Nut	2
20	25-2475	Cartridge Assembly	1
21	25-2476	O-Ring	1
22	4881-1081-0	Pivot Arm Weldment	1
23	53-102	Wear Sleeve 1.25 O.D. x 1.012 I.D. x 1.00	1
24	53-126	Wear Sleeve .75 O.D. x .51 I.D. x .50	1
25	53-137	Wear Sleeve - 1.00 OD x .760 ID x 1.19	1
26	62-199	3/4NC x3-1/2" GD5 Cap Screw	1
27	64-113	3/4" STD. Flat Washer	1
28	63-162	3/4NC Nylon-Top Lock Nut	1
29	4881-0000-36	Spacer	1
30	60-602	3/16" DIA. x 1" Roll Pin	2
31	60-211	1/2" DIA. x 1-1/2" Clevis Pin	1
32	60-725	5/32" DIA. x 1-1/2" Cotter Pin	1
33	4881-1085-0	Spring Tube Weldment	1
34	4881-1083-0	Spring Clevis Weldment	1
35	62-377	1/2NC x 4" GD5 Cap Screw	1
36	63-108	1/2NC Nylon-Top Lock Nut	3
37	76-232	Spring	1
38	4881-1083-2	"H" Plate	1
39	4881-1080-3	Collar	1
40	4881-1080-2	Bushing	1
41	62-151	1/2NC x 3" GD5 Cap Screw	1
42	4881-1086-0	Pin Weldment	1
43	62-569	1/2NC x 1-1/2" GD5 Cap Screw	1
44	64-108	1/2" STD. Flat Washer	1
45	★ 4830-117-0	Maintenance Lock Assembly (Includes ■ Items)	2
46	■ 4830-117-1	Cylinder Lock	1
47	■ 60-103	P.T.O. Pin	1
	■ 74-387	Decal (not shown)	1

★ Storage location for 5 Shank & 7 Shank Rigid Models ONLY

# DECAL & SMV MOUNT




REV. 6/02  
M4881-63

## FOR MODELS - ALL

6/02

Item	Part Number	Part Description	Qty.
1	4881-0-2	Decal & SMV Mount	1
2	4881-0-1	Mounting Bracket	2
3	61-244	U-Bolt, 1/2" DIA. x 6-1/16" W x 5-1/4" L	2
4	64-107	1/2" STD. Lock Washer	6
5	63-106	1/2NC Hex Nut	6
6	62-420	1/2NC x 1-1/4" GD5 Cap Screw	2
7	64-108	1/2" STD. Flat Washer	2
8	5630-0-34	SMV Bracket	1
9	62-493	3/8NC x 3/4"	2
10	64-103	3/8" STD. Lock Washer	2
11	63-102	3/8NC Hex Nut	2
12	74-487	SMV Sign	1
13	62-507	1/4NC x 3/4" GD5 Cap Screw	3
14	64-101	1/4" STD. Flat Washer	3
15	64-100	1/4" STD. Lock Washer	3
16	63-100	1/4NC Hex Nut	3

# CENTER ROCKER ASSEMBLY




REV. 6/02  
M4881-26

## FOR MODELS - 5 & 7 RIGID SHANK

8/20/02

Item	Part Number	Part Description	Qty.
1	4881-9010-0A	Center Rocker Weldment	1
2	65-101	1/8 STD. Zerk	2
3	53-113	Wear Sleeve	4
4	53-109	Wear Sleeve	2
5	53-166	Wear Sleeve	4
6	4881-7084-0A	Link Weldment	1
7	64-129	1-1/2" STD. Flat Washer	2
8	76-164	Spring	1
9	4881-0000-12	Spacer	1
10	63-181	1-1/2NC Slotted Hex Nut	1
11	60-617	3/8"DIA. x 2-1/2" Roll Pin	1
12	see page P16	Walking Beam	2
13	4987-0-1	Rocker Pivot Pin	2
14	62-154	1/2NC x 3-1/2" GD5 Cap Screw	2
15	63-107	1/2NC Lock Nut	2
16	4881-0000-33	Rocker Pivot Pin	1
17	60-606	1/4" DIA. x 2" Roll Pin	6
18	4716-0-10	Cylinder Link Pin	2

# CENTER ROCKER ASSEMBLY




## FOR MODELS - 7 SHANK FOLDING

8/20/02

Item	Part Number	Part Description	Qty.
1	4881-9010-0A	Center Rocker Weldment	1
2	65-101	1/8 STD. Zerk	2
3	53-113	Wear Sleeve	4
4	53-109	Wear Sleeve	2
5	53-166	Wear Sleeve	4
6	4881-7084-0A	Link Weldment	1
7	64-129	1-1/2" STD. Flat Washer	2
8	76-164	Spring	1
9	4881-0000-12	Spacer	1
10	63-181	1-1/2NC Slotted Hex Nut	1
11	60-617	3/8"DIA. x 2-1/2" Roll Pin	1
12	see page P17	Walking Beam	2
13	4987-0-1	Rocker Pivot Pin	2
14	62-154	1/2NC x 3-1/2" GD5 Cap Screw	2
15	63-107	1/2NC Lock Nut	2
16	4881-0000-33	Rocker Pivot Pin	1
17	60-606	1/4" DIA. x 2" Roll Pin	6
18	4716-0-10	Cylinder Link Pin	2

# CENTER ROCKER ASSEMBLY




REV. 8/02  
M4881-28

## FOR MODELS - 9 SHANK FOLDING

8/20/02

Item	Part Number	Part Description	Qty.
1	4881-1010-0	Center Rocker Weldment	1
2	65-101	1/8 STD. Zerk	2
3	53-113	Wear Sleeve	8
4	53-109	Wear Sleeve	2
5	53-166	Wear Sleeve	4
6	4881-7084-0A	Link Weldment	1
7	64-129	1-1/2" STD. Flat Washer	2
8	76-164	Spring	1
9	4881-0000-12	Spacer	1
10	63-181	1-1/2NC Slotted Hex Nut	1
11	60-617	3/8"DIA. x 2-1/2" Roll Pin	1
12	see page P18	Walking Beam	2
13	4987-0-1	Rocker Pivot Pin	2
14	62-154	1/2NC x 3-1/2" GD5 Cap Screw	2
15	63-107	1/2NC Lock Nut	2
16	4881-0000-33	Rocker Pivot Pin	1
17	60-606	1/4" DIA. x 2" Roll Pin	6
18	4716-0-10	Cylinder Link Pin	2

# WING ROCKER ASSEMBLY




REV. 7/02  
M4881-53

**FOR MODELS - TL3000 7 SHANK**

**6/02**

Item	Part Number	Part Description	Qty.
1	4881-9013-0	Left Wing Rocker Weldment	1
2	4881-9012-0	Right Wing Rocker Weldment	1
3	See page P19	Hub Assembly - 6 Bolt	2
4	62-203	3/4NC x 4-1/2" GD5 Cap Screw	8
5	64-112	3/4" STD. Lock Washer	8
6	63-112	3/4NC Hex Nut	8
7	4987-0-1	Rocker Pivot Pin	2
8	62-154	1/2NC x 3-1/2" GD5 Cap Screw	2
9	63-107	1/2NC Lock Nut	2
10	4716-0-10	Cylinder Pin	2
11	53-113	Wear Sleeve	4
12	60-606	1/4" DIA. x 2" Roll Pin	4
13	53-149	Wear Sleeve	2
14	4815-44-0	Stud Weldment	2
15	64-118	1" STD. Lock Washer	2
16	63-117	1NC Hex Nut	2
17	62-569	1/2NC x 1-1/2" GD5 Cap Screw	2
18	64-107	1/2" STD. Lock Washer	2
19	63-106	1/2NC Hex Nut	2
20	4881-7000-1	Spacer Plate	2

# WING ROCKER ASSEMBLY




FOR MODELS - TL3000 9 SHANK

6/02

Item	Part Number	Part Description	Qty.
1	4881-9013-0	Left Wing Rocker Weldment	1
2	4881-9012-0	Right Wing Rocker Weldment	1
3	4987-0-1	Rocker Pivot Pin	2
4	62-154	1/2NC x 3-1/2" GD5 Cap Screw	2
5	63-107	1/2NC Lock Nut	2
6	53-113	Wear Sleeve	4
7	53-149	Wear Sleeve	2
8	4716-0-10	Cylinder Pin	2
9	60-606	1/4" DIA. x 2" Roll Pin	4
10	4815-44-0	Stud Weldment	2
11	64-118	1" STD. Lock Washer	2
12	63-117	1NC Hex Nut	2
13	62-569	1/2NC x 1-1/2" GD5 Cap Screw	2
14	64-107	1/2" STD. Lock Washer	2
15	63-106	1/2NC Hex Nut	2
16	53-108	Wear Sleeve	2
17	4881-0000-11	Flat Spring	2
18	62-432	5/16NC x 1" GD5 Cap Screw	4
19	63-167	5/16NC Nylon-Top Lock Nut	4
20	See Page P20	Walking Beam	2

# WALKING BEAM ASSEMBLY



REV. 5/6/02  
M4881-30


**FOR MODELS - TL3000 5 & 7 SHANK RIGID CENTER SECTION**

**6/02**

Item	Part Number	Part Description	Qty.★
1	41-210	Cup	2
2	41-114	Cone	2
3	42-131	Clark Seal	2
4	4987-9-1	Pivot Spindle	1
5	4987-54-0	Walking Beam Weldment (Includes Item 8 Wear Sleeves)	1
6	62-178	5/8NC x 4" GD5 Cap Screw	1
7	63-110	5/8NC Lock Nut	1
8	53-108	Wear Sleeve	2
9	2490-90-3	Bushing	1
10	64-167	Special Washer	1
11	63-231	1-1/4NF Slotted Hex Nut	1
12	60-710	1/4" DIA. x 2-1/2" Cotter Pin	1
13	42-109	Seal	2
14	41-114	Cone	2
15	● 41-210	Cup	2
16	● 2135-14-0A	Repair Hub - 6 Bolt (Includes 1 ea. of ● Items)	2
17	● 65-122	1/4 x 65° Drive Zerk	4
18	● 62-295	Wheel Bolt - 9/16NF x 1-1/8" GD5	12
19	● 41-208	Cup	2
20	41-112	Cone	2
21	64-120	1" SAE Flat Washer	2
22	63-204	1NF Slotted Hex Nut	2
23	60-702	3/16" DIA. x 1-1/2" Cotter Pin	2
24	52-302	Hub Cap	2

★ NOTE: Quantites shown are for ONE Walking Beam

# WALKING BEAM ASSEMBLY




**FOR MODELS - TL3000 7 SHANK FOLD - CENTER SECTION**

**6/02**

Item	Part Number	Part Description	Qty.*
1	41-210	Cup	2
2	41-114	Cone	2
3	42-131	Clark Seal	2
4	4987-9-1	Pivot Spindle	1
5	4987-54-0	Walking Beam Weldment (Includes Item 8 Wear Sleeves)	1
6	62-178	5/8NC x 4" GD5 Cap Screw	1
7	63-110	5/8NC Lock Nut	1
8	53-108	Wear Sleeve	2
9	2490-90-3	Bushing	1
10	64-167	Special Washer	1
11	63-231	1-1/4NF Slotted Hex Nut	1
12	60-710	1/4" DIA. x 2-1/2" Cotter Pin	1
13	42-109	Seal	2
14	41-114	Cone	2
15	• 41-210	Cup	2
16	• 2490-96-0	Repair Hub - 8 Bolt (Includes 1 ea. of • Items)	2
17	• 62-311	Wheel Bolt - 5/8NF x 2-1/4" GD5	16
18	• 63-208	5/8NF Lug Nut	16
19	• 65-122	1/4 x 65° Drive Zerk	4
20	• 41-208	Cup	2
21	41-112	Cone	2
22	64-120	1" SAE Flat Washer	2
23	63-204	1NF Slotted Hex Nut	2
24	60-702	3/16" DIA. x 1-1/2" Cotter Pin	2
25	52-302	Hub Cap	2

\* NOTE: Quantities shown are for ONE Walking Beam

# WALKING BEAM ASSEMBLY



REV. 6/02  
M4881-31


## FOR MODELS - TL3000 9 SHANK FOLD - CENTER

6/02

Item	Part Number	Part Description	Qty. ★
1	41-220	Cup	2
2	41-122	Cone	2
3	42-135	Seal	2
4	4881-1054-0	Walking Beam Weldment	1
5	53-175	Wear Sleeve	1
6	4881-1009-1	Spindle	1
7	62-178	5/8NC x 4" GD5 Cap Screw	1
8	63-110	5/8NC Lock Nut	1
9	53-174	Wear Sleeve	2
10	● 4881-1096-0	Repair Hub Assembly (Includes 1 ea of ● items)	2
11	42-136	Seal	2
12	41-124	Cone	2
13	● 41-222	Cup	2
14	● 62-311	5/8NF x 2-1/4" Wheel Bolt	16
15	● 63-208	5/8NF Lug Nut	16
16	● 65-122	1/4 x 65° Drive Zerk	4
17	● 41-221	Cup	2
18	41-123	Cone	2
19	64-138	Special Washer	2
20	63-205	1-1/4NF Slotted Hex Nut	2
21	60-708	1/4" DIA. x 1-3/4" Cotter Pin	2
22	52-302	Hub Cap	2
23	4881-1009-2	Bushing	1
24	64-167	Special Washer	1
25	63-231	1-1/4NF Slotted Hex Nut	1
26	60-710	1/4" DIA. x 2-1/2" Cotter Pin	1

★ NOTE: Quantities shown are for ONE Walking Beam

# HUB ASSEMBLY



REV 6/02  
M4881-32

## FOR MODELS - TL3000 7 SHANK FOLD - WING


6/02

Item	Part Number	Part Description	Qty.★
1	2135-12-0	Stub Axle Weldment	1
2	● 2135-14-0A	Repair Hub (Includes ● Items)	1
3	● 62-295	9/16NF Wheel Bolt	6
4	42-109	Seal	1
5	41-114	Cone	1
6	● 41-210	Cup	1
7	● 41-208	Cup	1
8	41-112	Cone	1
9	63-204	1-1/4NF Slotted Hex Nut	1
10	60-702	3/16" DIA. x 1-1/2" Cotter Pin	1
11	52-302	Hub Cap	1
12	53-108	Wear Bushing	1
13	■ 64-203	3/4NC x 4-1/2" GD5 Cap Screw	4
14	■ 64-112	3/4" STD. Lock Washer	4
15	■ 63-112	3/4NC Hex Nut	4
16	● 65-122	1/4 x 65° Drive Zerk	2
17	64-120	1" SAE Black Flat Washer	1

■ Not included in Hub Assembly

★ NOTE: Quantities shown are for (1) Hub Assembly

# WALKING BEAM ASSEMBLY




**FOR MODELS - TL3000 9 SHANK - WING**

**8/20/02**

Item	Part Number	Part Description	Qty.★
1	4987-49-0	Walking Beam Weldment	1
2	53-105	Wear Sleeve	2
3	● 1918-14-0A	Repair Hub Assembly (Includes 1 Ea. of ● Items)	2
4	4987-29-1	Pivot Spindle	1
5	62-509	5/8NC x 3" GD5 Cap Screw	2
6	63-110	5/8NC Lock Nut	1
7	64-167	Special Washer	1
8	63-231	1-1/4NF Slotted Hex Nut	1
9	60-710	1/4" DIA. x 2-1/2" Cotter Pin	1
10	42-108	Seal	2
11	41-113	Cone	2
12	● 41-209	Cup	2
13	● 62-295	Wheel Bolt	12
14	● 65-122	1/4 x 65° Drive Zerk	4
15	● 41-208	Cup	2
16	41-112	Cone	2
17	64-120	1" SAE Black Flat Washer	2
18	60-702	3/16" DIA. x 1-1/2" Cotter Pin	2
19	63-204	1NF Slotted Hex Nut	2
20	52-302	Hub Cap	2
21	4987-53-2	Plate	1
22	62-199	3/4NC x 3-1/2" GD5 Cap Screw	8
23	64-112	3/4" STD. Lock Washer	8
24	63-112	3/4NC Hex Nut	8
25	4987-53-0	Walking Beam Hub	1
26	65-101	1/8NPT STD. Zerk	1
27	41-208	Cup	2
28	41-121	Cone Assembly	2
29	4218-13-3	Special Washer	1
30	4987-29-2	Bushing	1

★ NOTE: Quantities shown are for ONE Walking Beam

# WHEELS & TIRES




M4881-11  
4-01

## FOR MODELS - ALL

6/02

Item	Part Number	Part Description	Qty.
1	1000-10580-0	Wheel and Tire Assembly, 6-Bolt	Specify
2	51-103	Tire - 10.00x 15, 8-Ply	1
3	74-109	Decal	1
4	51-107	#415 Valve Stem	1
5	52-103	Wheel - 15 x 10, 6-Bolt	1
1	1000-12520-01	Wheel and Tire Assembly, 8-Bolt, 12.5L	Specify
2	51-103	Tire - 12.5L x 15, 12-Ply	1
3	74-109	Decal	1
4	51-107	#415 Valve Stem	1
5	52-103	Wheel - 15 x 10, 8-Bolt	1
1	1000-12540-01	Wheel and Tire Assembly, 8-Bolt, 12.5L	Specify
2	51-132	Tire - 12.5L x 15, Load Range F, Highway Service	1
3	74-109	Decal	1
4	51-107	#415 Valve Stem	1
5	52-114	Wheel - 15 x 10, 8-Bolt	1
1	1000-16540-01	Wheel and Tire Assembly, 8-Bolt, 16.5L	Specify
2	51-134	Tire - 16.5L x 16.1 Load Range F1	1
3	74-109	Decal	1
4	51-107	#415 Valve Stem	1
5	52-115	Wheel - 16.1 x 14, 8-Bolt Non-Rev.	1

**GANG BEAM ASSEMBLY**  
(REAR GANG SHOWN)



Rev. 8/13/01  
M4881-5

**MODEL 7R ONLY**

# GANG BEAM ASSEMBLY

FOR MODELS - TL3000 5, 7, 9 SHANK

8/20/02


Item	Part Number	Part Description	Qty	Item	Part Number	Part Description	Qty
1	4881-5034-0	5 Shank Rt. Front Beam	1	18	65-123	1/8NPT Extended Zerk	
	4881-5035-0	5 Shank Lt. Front Beam	1	19	64-113	3/4" Flat Washer	
	4881-5036-0	5 Shank Rt. Rear Beam	1	20	64-112	3/4" Lock Washer	
	4881-5037-0	5 Shank Lt. Rear Beam	1	21	63-112	3/4NC Hex Nut	
	4881-7134-0	7 Shank Rt. Front Beam	1	22	61-119	U-Bolt, 5/8	
	4881-7135-0	7 Shank Lt. Front Beam	1	23	64-110	5/8" Flat Washer	
	4881-7136-0	7 Shank Rt. Rear Beam	1	24	64-109	5/8" Lock Washer	
	4881-7137-0	7 Shank Lt. Rear Beam	1	25	63-109	5/8NC Hex Nut	
	4881-7034-0	7 & 9 Shank Front Beam	2	26	4885-0-1A	Lt. Scraper Arm	
	4881-7036-0	7 & 9 Shank Rt. Rear Beam	1	27	4885-0-2A	Rt. Scraper Arm	
	4881-7037-0	7 & 9 Shank Lt. Rear Beam	1	28	61-111	U-Bolt, 3/4D x 6.06W x 7.50L	
	4881-7038-0	7 Shank Rt. Front Wing Beam	1	29	2410-0-1	Shank Base	
	4881-7039-0	7 Shank Lt. Front Wing Beam	1	30	31-185	Shank, 1-1/4 x 2-1/2"	
	4881-7040-0A	7 Shank Rt. Rear Wing Beam	1	31	2410-0-2	Bolt Plate	
	4881-7041-0A	7 Shank Lt. Rear Wing Beam	1	32	53-101	Wear Sleeve	
	4881-9038-0	9 Shank Rt. Front Wing Beam	1	33	53-102	Wear Sleeve	
	4881-9039-0	9 Shank Lt. Front Wing Beam	1	34	32-114	Scraper Blade (Lt. Fr. - Rt. Rr.)	
	4881-9040-0	9 Shank Rt. Rear Wing Beam	1	35	32-115	Scraper Blade (Rt. Fr. - Lt. Rr.)	
	4881-9041-0	9 Shank Lt. Rear Wing Beam	1	36	63-106	1/2NC Hex Nut	
2	★ 4881-7028-0	Outside Pivot Weldment	4	37	64-107	1/2" Lock Washer	
3	★ 53-109	Wear Sleeve	16/ 32	38	4907-186-3	Clamp	
4	60-710	Cotter Pin, 1/4 x 2-1/2	8/ 16	39	61-145	U-Bolt, .50D x 2.06W x 3.50L	
5	4881-78-0	Pin Weldment	8/ 16	40	2008-1-625	62-1/2" Scraper Tube	
6	★ 60-212	Clevis Pin, 1/2 x 2	2/4		2008-1-705	70-1/2" Scraper Tube	
7	★ 60-716	#3 Hair Pin Cotter	2/4		2008-1-104	104" Scraper Tube	
8	★ 4881-5026-0	Slide Arm Weldment	2/4		2008-1-1085	108-1/2" Scraper Tube	
	4881-7026-0	7 Shank Slide Arm Weldment	2		2008-1-535	53-1/2" Scraper Tube	
9	★ 4885-0-9	1-1/2" Heavy Washer	2/4		2007-1-370	37" Scraper Tube	
10	★ 63-181	1-1/2NC Slotted Nut	4/8		2008-1-545	54-1/2" Scraper Tube	
11	★ 60-103	PTO Lock Pin	2/4	41	63-125	1-1/4NC Slotted Hex Nut	8/ 16
12	★ 4881-7024-0	Inside Pivot Weldment	2/4	42	64-129	1-1/2"STD Flat Washer	
13	45-106	Side Ring		43	● 4881-7035-0	Bolt On Lug	2
14	40-166	Bearing Assm., Sq. Bore		44	● 61-120	3/4" DIA. U-Bolts	4
15	62-217	3/4NC x 7-1/2"GD5 Cap Screw					
16	2410-10-2	Lower Brg. Housing					
17	2410-10-1	Upper Brg. Housing					

★ Rear Gangs ONLY

● Used for 7 Shank Rigid Models ONLY



# DISC GANG ASSEMBLY




Rev. 4/11/01  
M4881-6

**FOR MODELS - TL3000 5, 7, 9 SHANK**

**6/02**

Item	Part Number	Part Description	Qty.
1	60-714	3/8" DIA. x 3-1/2" Cotter Pin	1
2	63-181	1-1/2NC GD5 Slotted Hex Nut	2
3	1441-0-17	End Spacer	2
4	64-136	Washer	1
5	1441-0-15	End Washer	1
6	4881-0000-21	Short Half Spool, 13" Spacing	Spec
	1441-0-14D	Short Half Spool, 11" Spacing	Spec
7	4881-0000-15	Long Half Spool, 11" & 13" Spacing	Spec
8	4881-0-7	13" Spacer Spool	Spec
	4881-0-8	11" Spacer Spool	Spec
9	4881-0000-25	Tie Rod, 1-1/2" sq. x 72-1/2"	
	4881-0000-29	Tie Rod, 1-1/2" sq. x 73-5/8"	
	4881-0000-26	Tie Rod, 1-1/2" sq. x 111-1/2"	
	4881-0000-28	Tie Rod, 1-1/2" sq. x 107-1/4"	
	4881-0000-27	Tie Rod, 1-1/2" sq. x 59-1/2"	
	4881-0000-30	Tie Rod, 1-1/2" sq. x 46-3/8"	
	4881-0000-32	Tie Rod, 1-1/2" sq. x 51-3/4"	
	4881-0000-24	Tie Rod, 1-1/2" sq. x 40-9/16"	
	4881-0000-20	Tie Rod, 1-1/2" sq. x 62"	
10	30-241	22" x 1/4" Plain Sharp Blade	Spec
	30-220	24" x 1/4" Plain Sharp Blade	Spec
	30-221	24" x 1/4" Notched Sharp Blade	Spec
	30-242	22" x 1/4" Notched Sharp Blade	Spec
11	30-149	20" x 7 Ga. Cut-Out Disc Blade	Spec
12	60-709	1/4 x 2" Roll Pin	1
13	63-180	1-1/8NC Slotted Hex Jam Nut	1
14	142-19-1	Spool Washer	1
15	62-270	1-1/8NC x 3-1/2" Special Bolt	1
16	1050-45-1	Extension Spool	1
17	62-167	5/8NC x 1-3/4" GD5 Cap Screw	4
18	64-109	5/8" STD. Lock Washer	4
19	63-109	5/8NC Hex Nut	4
20	1441-0-16	End Washer	1
21	60-617	3/8 x 2-1/2 Roll Pin	1
22	64-124	1-1/8" SAE Flat Washer	1

# SUBSOIL SHANK ASSEMBLY




Rev.6/02  
M4881-25

**FOR MODELS - ALL**

Rev.6/02

Item	Part Number	Part Description	Qty	Item	Part Number	Part Description	Qty
1	4885-93-0	Link Weldment	1	23	53-117	Wear Sleeve, 1.25 od x 1.02 id x 1.25	1
2	4885-98-0	Right Shear Plate Weldment	1	24	4881-0000-10	Bolt Plate	1
3	4885-97-0	Left Shear Plate Weldment	1	25	62-651	1NC x 9 GD5 Machine Bolt	2
4	53-136	Wear Sleeve, 1.00 od x .76 id x .50	2	26	64-118	1 Lock Washer	4
5	53-103	Wear Sleeve	2	27	63-117	1NC Hex Nut	4
6	4885-80-2	Spacer Tube	1	28	60-608	Roll Pin, 1/4 DIA. x 2-1/2	2
7	4885-80-3	1NC x 4" Special Bolt	1	29	62-817	1NC x 3-1/2" GD8 Cap Screw	2
8	63-119	1NC Lock Nut	2	30	31-203	Subsoil Shank	1
9	62-742	1-1/4NC x 5-1/2 GD5 Cap Screw	2	31	62-372	1/2NC x 2-1/2 GD5 Cap Screw	1
10	63-126	1-1/4NC Lock Nut	2	32	4885-96-0	Wear Bar Weldment	1
11	62-205	3/4NC x 5 GD5 Cap Screw	1	33	63-107	1/2NC Lock Nut	1
12	63-162	3/4NC Nylon-Top Lock Nut	1	34	33-206	Subsoil Point w/ Wing	1
13	62-339	5/8NC x 4-1/2 GD5 Cap Screw	2	35	60-127	Spiral Expansion Pin, 3/8 x 2-1/2"	1
14	4808-26-3	Spacer Block	1	36	33-207	Subsoil Point	1
15	63-110	5/8NC Lock Nut	6	37	33-203	Hard Faced Subsoil Point w/Boot	1
16	62-242	1NC x 4 GD5 Cap Screw	1				
17	62-441	5/8NC x 2-1/2" GD5 Cap Screw	4				
18	64-110	5/8" STD. Flat Washer	12				
19	4885-76-1	Doubler	1				
20	31-190	Shank Arm	2				
21	4881-9090-0	Shank Mount Weldment	1				
22	53-101	Wear Sleeve, 1.50 od x 1.28 id x 1.00	3				


# SUBSOIL SHANK ASSEMBLY




**FOR MODELS - ALL**

**6/02**

Item	Part Number	Part Description	Qty	Item	Part Number	Part Description	Qty
1	4885-90-0A	Spring Assembly	1	24	53-101	Wear Sleeve	3
2	65-110	1/8 Drive Zerk	1	25	4881-9090-0	Shank Mount Weldment	1
3	4885-87-0C	Lt. Trunnion Bracket Assembly	1	26	60-608	Roll Pin, 1/4 DIA. x 2-1/2	2
4	4885-88-0C	Rt. Trunnion Bracket Assembly	1	27	4885-96-0	Wear Bar Weldment	1
5	63-107	1/2NC Lock Nut	4	28	62-372	1/2NC x 2-1/2 GD5 Cap Screw	1
6	62-351	1/2NC x 4-1/2 GD5 Cap Screw	4	29	63-107	1/2NC Lock Nut	1
7	4885-80-1	Spacer Tube	4	30	33-206	Subsoil Point w/ Wing	1
8	53-136	Wear Sleeve, 1.00 od x .76 id x .50	2	31	60-127	Spiral Expansion Pin, 3/8 x 2-1/2"	1
9	62-742	1-1/4NC x 5-1/2 GD5 Cap Screw	2	32	33-203	Hard Faced Subsoil Point w/Boot	1
10	4885-80-2	Spacer Tube	2	33	33-207	Subsoil Point	1
11	63-126	1-1/4NC Lock Nut	2	34	4881-0000-10	Bolt Plate	1
12	4885-80-3	1NC x 4" Special Bolt	1	35	62-651	1NC x 9 GD5 Machine Bolt	2
13	31-203	Subsoil Shank	1	36	64-118	1 Lock Washer	4
14	63-119	1NC Lock Nut	2	37	63-117	1NC Hex Nut	4
15	62-205	3/4NC x 5 GD5 Cap Screw	1	38	62-817	1NC x 3-1/2" GD8 Cap Screw	2
16	63-162	3/4NC Nylon-Top Lock Nut	1	39	4885-76-1	Doubler	1
17	62-339	5/8NC x 4-1/2 GD5 Cap Screw	2	40	64-110	5/8" STD. Flat Washer	12
18	4808-26-3	Spacer Block	1	41	53-170	Wear Sleeve .815 od x .51 id x .50	2
19	63-110	5/8NC Lock Nut	6				
20	62-441	5/8NC x 2-1/2"GD5 Bolt	4				
21	31-190	Shank Arm	2				
22	62-242	1NC x 4 GD5 Cap Screw	1				
23	53-148	Wear Sleeve, 1.25 od x 1.02 id x 1.50	1				








## DEPTH HYDRAULIC ASSEMBLY

FOR MODELS - TL3000 7 SHANK, 9 SHANK FOLDING

8/02

Item	Part Number	Part Description	Qty.
1	4881-71-0	1/2 x 95 Hose, Black/Black	1
2	4881-77-0	1/2 x 95 Hose, Red/Black	1
3	25-309	Hyd Fit O/R 37° Flare Tee	
4	25-300	3/4M O/R to 3/4M JIC Adapter	
5	25-2272	Transport Lock	1
6	25-320	Hyd Fit O/R 37° Flare 90° F	
7	25-2474	Remote Valve	
8	24-337R	1/2 x 122 Hose	1
9	24-314R	1/2 x 90 Hose	1
10	25-128	Steel Hose Wrap	1
11	24-238R	3/8 x 192 Hose	1
12	24-231R	3/8 x 176 Hose	1
13	24-223R	3/8 x 128 Hose	1
14	24-2103R	3/8 x 250 Hose	1
15	24-259R	3/8 x 202 Hose	1
16	21-1029	4-1/2 x 16 Hyd Cyl	2
17	24-2100R	3/8 x 164 Hose	
18	25-1153	5/8 ID Hose Clamp	Spec
19	62-491	3/8NF x 3/4 GD5 Cap Screw	Spec
20	62-111	3/8NC x 1-1/2 GD5 Cap Screw	4
21	63-134	3/8NC Nylon-Top Lock Nut	4
22	4881-5040-0	Hose Stand Weldment	1
23	60-708	1/4 x 1-3/4 Cotter Pin	1
24	25-127	Hose Clamp	2
25	25-301	Hyd Fit 3/4M O/R - 3/4M JIC 90°	8
26	2426-170-5	Hose Bracket	2
27	62-692	3/8NF x 1" GD5 Cap Screw	2
28	21-1028	4" x 16" Series Hydraulic Cylinder	2
29	25-303	37° Flare 3/4(M) Tee Hydraulic Fitting	1



NOTE: RUN HOSES DOWN RIGHT INSIDE OF TONGUE

NOTE: HOSES ON BOTTOM SIDE OF FRAME WHENEVER POSSIBLE


Replace both bolts  
W/JH (2) 62-394  
5/16 x 2 1/2 HHCS

## WING FOLD HYDRAULICS ASSEMBLY

FOR MODELS - TL3000 7 SHANK FOLD, 9 SHANK

6/02

Item	Part Number	Part Description	Qty.
1	4881-70-0	3/8 x 95 Hose, Red/Yellow	
2	4881-76-0	3/8 x 95 Hose, Yellow/Yellow	
3	4881-0000-22	Mounting Plate	
4	62-507	1/4NC x 3/4 GD5 Cap Screw	
5	64-100	1/4 Lock Washer	
6	63-100	1/4NC Hex Nut	
7	62-394	5/16NC x 2-1/2 GD5 Cap Screw	
8	25-2272	Transport Lock	
9	25-301	Hyd Fit 3/4M O/R - 3/4M JIC 90°	
10	24-2117R	3/8 x 259 Hose	
11	24-2109R	3/8 x 114 Hose	
12	25-128	Steel Hose Wrap	
13	4956-75-0	90° Restrictor w/ Tag	
14	21-189	5 x 32 Hyd Cyl	
15	24-272R	3/8 x 45 Hose	
16	24-246R	3/8 x 28 Hose	
17	25-310	Hyd Fit 3/4M JIC to 3/4F JIC 90° Swivel	
18	25-303	Hyd Fit 37° Flare 3/4M Tee	
19	25-1153	5/8 ID Hose Clamp	
20	62-491	3/8NF x 3/4 GD5 Cap Screw	
21	62-111	3/8NC x 1-1/2 GD5 Cap Screw	
22	63-134	3/8NC Nylon-Top Lock Nut	
23	4881-5040-0	Hose Stand Weldment	
24	60-708	1/4 x 1-3/4 Cotter Pin	
25	25-127	Hose Clamp	
26	25-306	O-Ring 37° Flare Tee Restrictor	
27	24-2115R	3/8 x 156" Hose	
28	2426-170-5	Hose Bracket	2
29	62-692	3/8NF x 1" GD5 Cap Screw	2
30	25-300	3/4M O/R to 3/4M JIC Adapter	



NOTE: HOSES ON BOTTOM SIDE OF FRAME  
WHENEVER POSSIBLE


ASSEMBLE VALVES TO BRACKET. "V" SIDE GOES TO TRACTOR; "C" SIDE CONNECTS TO CYLINDER

# HYDRAULIC GANG ASSEMBLY

**FOR MODELS - TL3000 5 SHANK, 7 SHANK RIGID**

6/02

<i>Item</i>	<i>Part Number</i>	<i>Part Description</i>	<i>Qty.</i>
1	4881-72-0	3/8 x 95 Hose, Blue/Blue Hose Grip	1
2	4881-73-0	3/8 x 95 Hose, Red/Blue Hose Grip	1
3	4881-74-0	3/8 x 95 Hose, Red/Gray Hose Grip	1
4	4881-75-0	3/8 x 95 Hose, Gray/Gray Hose Grip	1
5	24-272R	3/8 x 45 Hose	4
6	25-301	Hyd Fit 3/4M O/R - 3/4M JIC 90°	6
7	25-320	Hyd Fit O/R 37° Flare 90° F	1
8	4956-75-0	Hyd Fit, Restrictor Elbow 90°	2
9	21-1003	4 x 8 Cylinder	2
10	24-218R	3/8 x 100 Hose	2
11	24-249R	3/8 x 238 Hose	
12	21-1002	3-3/4 x 8 Cylinder	2
13	25-304	Hyd Fit 37° Flare Male Coupler	2
14	24-212R	3/8 x 79 Hose	
15	25-1153	Hose Clamp - 5/8"	Spec
16	62-491	3/8NF x 3/4 GD5 Cap Screw	Spec
17	25-127	Hose Clamp - 3/4"	Spec
18	62-111	3/8 x 1-1/2 Cap Screw	4
19	63-134	3/8NC Nylon-Top Lock Nut	4
20	4881-5040-0	Hose Stand	1
21	60-708	1/4 x 1-3/4 Cotter Pin	
22	25-2278	Hydraulic Lock Valve (to Rear Disc Gangs)	1
23	25-328	Hyd Fit 9/16 O/R to 3/4M JIC	8
24	62-806	1/4 x 3-1/2 GD5 Cap Screw	
25	64-100	1/4 Lock Washer	
26	63-100	1/4NC Hex Nut	
27	24-241R	3/8 x 154" Hose	1
28	24-225R	3/8 x 140" Hose	1
29	24-206R	3/8 x 57" Hose	1
30	25-128	Steel Hose Wrap	
31	2426-170-5	Hose Bracket	2
32	62-692	3/8NF x 1" GD5 Cap Screw	2
33	25-2278	Hydraulic Lock Valve (to Front Disc Gangs)	1
34	25-314	O-Ring 37° Female Flare Hydraulic Fitting	1
35	25-151	2000 PSI Relief Valve	1
36	25-300	3/4(M)O-Ring to 3/4(M)JIC Hydraulic Fitting	2
37	24-235R	3/8 x 16 Black 2W Hose Assembly	1
38	25-310	3/4(M)JIC to 3/4(F)JIC 90° Swivel Hydraulic Fitting	1
39	25-317	3/4 O-Ring Plug	1
40	25-307	37° Flare Male / Female Tee Hydraulic Fitting	1



NOTE: RUN HOSES DOWN RIGHT INSIDE OF TONGUE

NOTE: HOSES ON BOTTOM SIDE OF FRAME WHENEVER POSSIBLE

36-48" BEYOND HITCH  
blue/red  
red/blue  
red/gray  
gray/gray  
55" hose & grip asm  
ASSEMBLY VALVES TO BRACKET  
"C" SIDE CONNECTS TO CYLINDER  
"V" SIDE GOES TO TRACTOR

32 END TO P AND V PORTS  
SLAVE CYLINDER  
18 HOSE TO MASTER CYLINDER


## DISC GANG HYDRAULIC ASSEMBLY

FOR MODELS - TL3000 7 SHANK FOLD, 9 SHANK

6/02

Item	Part Number	Part Description	Qty.
1	4881-72-0	3/8 x 95 Hose, Blue/Blue	
2	4881-73-0	3/8 x 95 Hose, Red/Blue	
3	4881-74-0	3/8 x 95 Hose, Red/Gray	
4	4881-75-0	3/8 x 95 Hose, Gray/Gray	
5	64-100	1/4 Lock Washer	
6	63-100	1/4NC Hex Nut	
7	25-301	Hyd Fit 3/4M O/R - 3/4M JIC 90°	
8	25-128	Steel Hose Wrap	
9	24-272R	3/8 x 45 Hose	
10	62-806	1/4NC x 3-1/2 GD5 Cap Screw	
11	25-2278	Hydraulic Lock Valve (to Rear Disc Gangs)	1
12	24-240R	3/8 x 107 Hose	
13	21-1004	4-1/4 x 8 Hyd Cyl	
14	24-250R	3/8 x 196 Hose	
15	25-301	Hyd Fit 3/4M O/R - 3/4M JIC 90°	
16	4956-75-0	90° Restrictor w/ Tag	
17	21-1005	4-1/2 x 8 Hyd Cyl	
18	24-218R	3/8 x 100 Hose	
19	21-1003	4 x 8 Hyd Cyl	
20	24-223R	3/8 x 128 Hose	
21	24-265R	3/8 x 135 Hose	
22	21-1002	3-3/4 x 8 Hyd Cyl	
23	25-304	Hyd Fit 37° Flare Male Coupler	
24	24-2116R	3/8 x 96" Hose	2
25	24-225R	3/8 x 140 Hose	
26	25-1153	5/8 ID Hose Clamp	
27	62-491	3/8NF x 3/4 GD5 Cap Screw	
28	62-111	3/8NC x 1-1/2 GD5 Cap Screw	
29	63-134	3/8NC Nylon-Top Lock Nut	
30	4881-5040-0	Hose Stand Weldment	
31	60-708	1/4 x 1-3/4 Cotter Pin	
32	24-230R	3/8 x 172 Hose	
33	25-328	Hyd Fit 9/16M O/R to 3/4M JIC	
34	25-127	Hose Clamp	
35	24-263R	3/8 x 227" Hose	
36	2426-170-5	Hose Bracket	2
37	62-692	3/8NF x 1" GD5 Cap Screw	2
38	25-2278	Hydraulic Lock Valve (to Front Disc Gangs)	1
39	25-314	O-Ring 37° Female Flare Fitting	1
40	25-151	2000 PSI Relief Valve	1
41	25-300	3/4(M) O-Ring to 3/4(M) JIC Hydraulic Fitting	2
42	24-235R	3/8 x 16" Black 2W Hose Assembly	1
43	25-310	3/4(M)JIC to 3/4(F)JIC 90° Swivel Hydraulic Fitting	1
44	25-317	3/4 O-Ring Plug	1
45	25-307	37° Flare Male / Female Tee Hydraulic Fitting	1
46	24-230R	3/8" x 172" Hose	1


# HYDRAULIC HOSE WITH PLASTIC GRIP ASSEMBLIES



REV 7/01  
M4881-23

Item	Part Number	Part Description	Qty.
	4881-70-0	3/8" x 95" 100R2 Hose with Red/Yellow Grip Assembly	1
1	24-2105R	3/8" x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2289	Hose Grip Half - Red	1
4	25-2290	Hose Grip Half - Yellow	1
5	62-656	Screw	4
	4881-71-0	1/2" x 95" 100R2 Hose with Black/Black Grip Assembly	1
1	24-330R	1/2" DIA. x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2291	Hose Grip Half - Black	1
4	25-2291	Hose Grip Half - Black	1
5	62-656	Screw	4
	4881-72-0	3/8" x 95" 100R2 Hose with Blue/Blue Grip Assembly	1
1	24-2105R	3/8" x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2509	Hose Grip Half - Blue	1
4	25-2509	Hose Grip Half - Blue	1
5	62-656	Screw	4
	4881-73-0	3/8" x 95" 100R2 Hose with Red/Blue Grip Assembly	1
1	24-2105R	3/8" x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2289	Hose Grip Half - Red	1
4	25-2509	Hose Grip Half - Blue	1
5	62-656	Screw	4
	4881-74-0	3/8" x 95" 100R2 Hose with Red/Gray Grip Assembly	1
1	24-2105R	3/8" x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2289	Hose Grip Half - Red	1
4	25-2510	Hose Grip Half - Gray	1
5	62-656	Screw	4
	4881-75-0	3/8" x 95" 100R2 Hose with Gray/Gray Grip Assembly	1
1	24-2105R	3/8" x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2510	Hose Grip Half - Gray	1
4	25-2510	Hose Grip Half - Gray	1
5	62-656	Screw	4
	4881-77-0	1/2" x 95" 100R2 Hose with Red/Black Grip Assembly	1
1	24-330R	1/2" x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2289	Hose Grip Half - Red	1
4	25-2291	Hose Grip Half - Black	1
5	62-656	Screw	4
	4881-76-0	3/8" x 95" 100R2 Hose with Yellow/Yellow Grip Assembly	1
1	24-2105R	3/8" DIA. x 95" JIC/ORB 100R2 Hose	1
2	25-2295	3/4 ORB to 1/2 NPT Hydraulic Fitting	1
3	25-2290	Hose Grip Half - Yellow	1
4	25-2290	Hose Grip Half - Yellow	1
5	62-656	Screw	4
6	★ 25-221	Male Coupler (Not Included in Assemblies above)	
★ Not Included in Hose and Grip Assemblies			

# PRINCE HYDRAULIC CYLINDER




6/01

**21-1002 3-3/4" X 8" PRINCE HYDRAULIC CYLINDER ASSEMBLY (Series) 6/02**  
**Retracted - 20-1/4" Extended - 28-1/4" Stroke - 8" Rod Diameter - 1-3/8"**

Item	Krause Number	Part Description	Qty.
1	21-2128	Piston Rod	1
2	21-694	Tube Assembly	1
3	21-272	Tie Rod Assembly	4
4	21-2105	Butt	1
5	21-803	Gland Assembly	1
6	21-804	Piston	1
7	21-2126	Clevis Assembly	1
8	21-225	Lock Nut	1
9	21-702	Port Plug	1
10	21-404	Port Plug	3
11	21-807	Bushing	1
12	21-260	Clevis Pin	2
13		3/16" DIA. x 1-3/4" Cotter Pin	4
14	★	Bearing Ring	2
15	★	O-Ring	1
16	★	O-Ring	1
17	★	O-Ring	2
18	★	Back-Up Washer	2
19	★	Teflon Seal	1
20	★	U-Cup	1
21	★	Wiper	1
22			
23			
24	21-2127	Bushing	2
25	74-113	Cylinder WARNING Decal	1
	21-808	Seal Kit (★ Items Included in Kit)	

# PRINCE HYDRAULIC CYLINDER



6/01

## 21-1003 4" X 8" PRINCE HYDRAULIC CYLINDER ASSEMBLY (Series)

6/02

Retracted - 20-1/4"


Extended - 28-1/4"

Stroke - 8"

Rod Diameter - 1-3/8"

Item	Krause Number	Part Description	Qty.
1	21-2128	Piston Rod	1
2	21-704	Tube Assembly	1
3	21-272	Tie Rod Assembly	4
4	21-882	Butt	1
5	21-810	Gland Assembly	1
6	21-811	Piston	1
7	21-2126	Clevis Assembly	1
8	21-225	Lock Nut	1
9	21-702	Port Plug	1
10	21-807	Bushing	1
11	21-404	Port Plug	3
12	21-2127	Bushing	2
13	21-260	Clevis Pin	2
14		3/16" DIA. x 1-3/4" Cotter Pin	4
15	★	Bearing Ring	2
16	★	O-Ring	1
17	★	O-Ring	1
18	★	O-Ring	2
19	★	Back-Up Washer	2
20	★	Teflon Seal	1
21	★	U-Cup	1
22	★	Wiper	1
23			
24			
25	74-113	Cylinder WARNING Decal	1
	21-2059	Seal Kit (★ Items Included in Kit)	

# PRINCE HYDRAULIC CYLINDER




6/01

**21-1004 4-1/4" X 8" PRINCE HYDRAULIC CYLINDER ASSEMBLY (Series) 6/02**  
**Retracted - 20-1/4" Extended - 28-1/4" Stroke - 8" Rod Diameter - 1-1/2"**

Item	Krause Number	Part Description	Qty.
1	21-2122	Piston Rod	1
2	21-2065	Tube Assembly	1
3	21-381	Tie Rod Assembly	4
4	21-2072	Butt	1
5	21-2073	Gland	1
6	21-2074	Piston	1
7	21-2125	Clevis Assembly	1
8	21-819	Lock Nut	1
9	21-702	Port Plug	1
10	21-2127	Bushing	2
11	21-404	Port Plug	3
12	21-2069	Bushing	1
13	21-260	Clevis Pin	2
14		3/16" DIA. x 1-3/4" Cotter Pin	4
15	★	Bearing Ring	2
16	★	O-Ring	1
17	★	O-Ring	1
18	★	O-Ring	2
19	★	Back-Up Washer	2
20	★	Teflon Seal	1
21	★	U-Cup	1
22	★	Wiper	1
23			
24			
25	74-113	Cylinder WARNING Decal	1
	21-2060	Seal Kit (★ Items Included in Kit)	

# PRINCE HYDRAULIC CYLINDER




6/01

**21-1005 4-1/2" X 8" PRINCE HYDRAULIC CYLINDER ASSEMBLY (SERIES) 6/02**  
**Retracted - 20-1/4" Stroke - 8" Extended - 28-1/4" Rod Diameter - 1-1/2"**

Item	Part Number	Part Description	Qty.
1	21-2122	Piston Rod	1
2	21-2140	Tube Assembly	1
3	21-715	Tie Rod Assembly	4
4	21-2083	Butt	1
5	21-2084	Gland	1
6	21-2085	Piston	1
7	21-2125	Clevis Assembly	1
8	21-819	Lock Nut	1
9	21-702	Plug ORB	1
10	21-2069	Bushing	2
11	21-404	Port Plug	3
12	21-2127	Bushing	1
13	21-260	Clevis Pin	2
14	21-639	3/16" DIA. x 1-3/4" Cotter Pin	4
15	★	Bearing Ring	1
16	★	O-Ring	1
17	★	O-Ring	1
18	★	O-Ring	2
19	★	Back-Up Washer	2
20	★	Teflon Seal	1
21	★	U-Cup	1
22	★	Wiper	1
23			
24			
25	74-113	Cylinder Warning Decal	1
	21-2080	Seal Kit (★ Items Included in Kit)	


# PRINCE HYDRAULIC CYLINDER



**21-1029 4-1/2" X 16" PRINCE HYDRAULIC CYLINDER ASSEMBLY (SERIES) 8/02**  
**Retracted - 31-1/2" Extended - 47-1/2" Stroke - 16" Rod Diameter - 2"**

Item	Part Number	Part Description	Qty.
1	21-2159	Piston Rod	1
2	21-2161	Tube Assembly	1
3	21-2164	Tie Rod Assembly	4
4	21-2163	Butt	1
5	21-2162	Gland Assembly	1
6	21-2160	Piston	1
7	21-819	Lock Nut	1
8	21-2154	Clevis Assembly	1
9	21-404	ORB Plug	1
10	21-702	Socket Head Plug	3
11	21-296	Clevis Pin	2
12		3/16" DIA. x 1-3/4" Cotter Pin	4
13	★	Teflon Seal	1
14	★	O-Ring	1
15	★	O-Ring	2
16	★	O-Ring	1
17	★	Back-Up Washer	2
18	★	U-Cup	1
19	★	Wiper	1
20	★	Bearing Ring	2
21	21-2158	Bushing (included in Item 5)	1
22	21-2157	Bushing (included in Item 8)	2
23	21-443	Series Decal	1
24	74-113	Cylinder Warning Decal	1
	21-2143	Seal Kit (★ Items Included in Kit)	

# PRINCE HYDRAULIC CYLINDER




6/01

**21-1028 4" X 16" PRINCE HYDRAULIC CYLINDER ASSEMBLY (SERIES) 6/02**  
**Retracted - 28-1/4"      Extended - 44-1/4"      Stroke - 16"      Rod Diameter - 1-3/4"**

Item	Part Number	Part Description	Qty.
1	21-2151	Piston Rod	1
2	21-2102	Tube Assembly	1
3	21-396	Tie Rod	4
4	21-882	Butt	1
5	21-2152	Gland Assembly	1
6	21-2153	Piston	1
7	21-2154	Clevis Assembly	1
8	21-819	Lock Nut	1
9	21-702	Port Plug	1
10	21-2157	Bushing (included in Item 7)	2
11	21-404	Port Plug	3
12	21-2156	Bushing (included in Item 5)	1
13	21-296	Clevis Pin	2
14		3/16" DIA. x 1-3/4" Cotter Pin	4
15	★	Bearing Ring	2
16	★	O-Ring	1
17	★	O-Ring	1
18	★	O-Ring	2
19	★	Back-Up Washer	2
20	★	Teflon Seal	1
21	★	U-Cup	1
22	★	Wiper	1
23			
24			
25	74-113	Cylinder Warning Decal	1
	21-2142	Seal Kit (★ Items Included in Kit)	

## PRINCE HYDRAULIC CYLINDER



**21-189 5" X 32" PRINCE HYDRAULIC CYLINDER ASSEMBLY**

6/02

Retracted - 43-3/4"


Stroke - 32"

Extended - 75-3/4"

Rod Diameter - 2"

Item	Part Number	Part Description	Qty.
1	21-917	Piston Rod	1
2	21-918	Tube	1
3	21-919	Tie Rod Assembly	4
4	21-868	Butt	1
5	21-869	Gland	1
6	21-870	Piston	1
7	74-113	Cylinder Warning Decal	1
8	21-871	Lock Nut	1
9	21-872	Clevis Pin	2
10		1/4" DIA. x 2" Roll Pin	4
11	21-404	Port Plug	3
12	★	Crown Seal	1
13	★	O-Ring	2
14	★	O-Ring	1
15	★	U-Cup	1
16	★	Wiper	1
17			
18	★	Bearing Ring	1
19	21-507	Clevis Assembly	1
20	★	Back-Up Washer	2
	● 21-858	Seal Kit (★ Items Included in Kit)	
	●	Not Included in Cylinder Assembly	

# CABLE GUIDE ASSEMBLY




**FOR MODELS - TL3000 5, 7, 9 SHANK w/ HYDRAULIC DISC GANGS**

8/20/02

Item	Part Number	Part Description	Qty.
1	4881-5051-0	Gauge Weldment	1
2	64-162	1/2" SAE Flat Washer	4
3	76-198	Spring	2
4	4881-5053-0	Left Gauge Pivot Weldment	1
5	62-422	1/4NC x 1-1/4" GD5 Cap Screw	4
6	4881-0000-7	Cable Spacer	3
7	64-101	1/4" STD. Flat Washer	6
8	63-164	1/4NC Lock Nut	4
9	62-120	3/8NC x 3" GD5 Cap Screw	1
10	63-103	3/8NC Lock Nut	1
11	64-104	3/8" STD. Flat Washer	3
12	72-133	Cable Assembly, Front	1
13	60-602	3/16" DIA. x 1" Roll Pin	2
14	72-134	Cable Assembly, Rear	1
15	4881-5052-0	Right Gauge Pivot Weldment	1
16	62-111	3/8NC x 1-1/2" GD5 Cap Screw	2
17	63-134	3/8NC Nylon-Top Lock Nut	2
18	74-530	Decal, Depth Gauge	2
19	4881-0000-50	Cable Guide	2
20	4881-0000-18	Lever Arm	1
21	62-459	5/16NC x 1-1/2" GD5 Cap Screw	1
22	63-167	5/16NC Lock Nut	2
23	70-217	Turnbuckle Assembly	1
24	61-263	U-Bolt, 1/2" DIA. x 4.06W x 7.25L	1
25	63-107	1/2NC Lock Nut	2

## DECALS & REFLECTORS



Rev. 6/02  
M4881-13


### FOR MODELS - ALL

6/02

Item	Part Number	Part Description	Qty.
1	74-276	Decal, Warning High Pressure	1
2	74-570	Decal, Warning Universal	1
3	74-465	Decal, Transport Lock	1
4	74-604	Decal, TL 3000	1
5	74-530	Decal, Depth	2
6	74-602	Decal, KRAUSE	3
7	74-606	Decal, Trademark	2
8	74-109	Decal, Notice Tighten Wheel Bolts	4/6/8
9	74-121	Decal, Warning Transport Width-Height	1
10	74-102	Decal, Warning Stand Clear	6
11	74-387	Decal, Notice Maintenance Lock	2
12	74-571	Decal, Transport Lock Wing (Rt)	1
	74-572	Decal, Transport Lock Wing (Lt)	1
	74-573	Decal, Transport Lock Wheel (Rt)	1
	74-574	Decal, Transport Lock Wheel (Lt)	1
13	74-113	Decal, Purge Cylinders	6/14
14	74-577	Amber Reflective Tape 2 x 9	6
15	74-489	Decal, Depth Setting	1

**NOTE: Additional Reflective Decals are part of light kit**

# LIGHT KIT ASSEMBLY



## FOR MODELS - ALL

6/02

Item	Part Number	Part Description	Qty.
1	79-397	Plug Receptacle	1
2	62-507	1/4NC x 3/4" GD5 Cap Screw	10
3	63-164	1/4NC Nylon-Top Lock Nut	10
4	79-297	Loom Clamp	6
5	79-553	Wire Harness, Tractor - 36'	1
6	25-126	Stay Strap	8
7	79-546	Center Harness	1
8	79-394	Amber Light Assembly	2
9	79-395	Red Light Assembly	2
10	4881-0000-9	Light Mount Bracket	2
11	4800-170-3	Strap	2
12	62-420	1/2NC x 1-1/4" GD5 Cap Screw	4
13	64-107	1/2" STD. Lock Washer	8
14	63-106	1/2NC Hex Nut	8
15	4881-9173-0	Left Light Bracket Assembly (Includes Items 16-18 Tape Decals)	1
16	4881-9174-0	Right Light Bracket Assembly (Includes Items 16-18 Tape Decals)	1
17	74-575	Red Reflective Tape 2 x 9	1
18	74-576	Orange Reflective Tape 2 x 9	1
19	74-577	Amber Reflective Tape 2 x 9	1
20	79-549	Wire Harness, Extension - 2'	2
21	79-551	Wire Harness, Extension - 4'	2
22	★ 62-352	1/2NC x 5-1/2" GD5 Cap Screw	4
	62-162	1/2NC x 7-1/2" GD5 Cap screw	4
23	79-552	Wire Harness, Retaining Clip	7
24	62-417	1NC x 1" GD5 Cap Screw	4

★ Model 730 Rigid Unit ONLY

# ASSEMBLY SECTION

THE FOLLOWING SECTION ILLUSTRATES A GENERAL METHOD FOR THE ASSEMBLY OF THIS SERIES KRAUSE TILLAGE TOOL. YOU MUST KNOW THE MODEL NUMBER OF THE UNIT BEING ASSEMBLED WHENEVER MAKING REFERENCE TO THIS SECTION. THE FOLLOWING PICTURES AND DRAWINGS WILL SHOW BOLTS, PINS, NUTS AND ETC., WITH THE DESCRIPTIVE SIZE AND LENGTHS IN THE ACCOMPANYING PARAGRAPH AND A PARTS LISTING REFERENCE PAGE NUMBER. IF ANY DIFFICULTY SHOULD BE ENCOUNTERED DURING THE ASSEMBLY, RECHECK THE ILLUSTRATIONS, ASSEMBLY STEPS AND PARTS LIST DRAWINGS.

# PROPER BOLT USE

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.


Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.


Tighten plastic insert or crimped steel-type lock nuts to approximately 110 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

*NOTE: "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication. **Tighten lubricated bolts to approximately 80% of dry bolts.***


BOLT SIZE	WRENCH SIZE	BLACK OR PLATED BOLTS		
		GRADE 2	GRADE 5	GRADE 8
3/8"	9/16"	20	33	45
7/16"	5/8"	32	52	70
1/2"	3/4"	50	80	105
5/8"	15/16"	100	150	210
3/4"	1-1/8"	160	260	375
7/8"	1-5/16"	175	415	600
1"	1-1/2"	250	625	880
1-1/8"	1-11/16"	375	850	1400
1-1/4"	1-7/8"	530	1100	1765
1-1/2"	2-1/4"	930	1400	2540




SAE  
GRADE 2



SAE  
GRADE 5



SAE  
GRADE 8



# ASSEMBLY INSTRUCTIONS

Shown here one method of assembly that can be accomplished with a small crew of assemblers. Each step of assembly is accompanied with a picture or shown by the parts illustration with the part names and bolt sizes listed.

**⚠ Warning:** Always attach chains securely. If a chain would break, the recoil action could cause the loose end to whip in any direction and injure any person nearby.

**Proof load rating of chain must equal or exceed 5 times the weight being lifted.**

THE HEAVIEST COMPONENT TO BE LIFTED INTO PLACE IS THE LARGE CENTER FRAME WHICH WEIGHS 3,200 LBS.


## MODEL NUMBERS

Know the model number of the field cultivator being assembled. Use the Model number whenever referring to the assembly, parts pages, or the placement pages. The number is stamped on the NAME PLATE located on the front frame member.




## I. CENTER FRAME & ROCKER ASSEMBLY

1. Place the center frame assembly on stands approximately 36" high in the center of the assembly area in a direction that will permit future hitching to a tractor. NOTE: The stands will be required to support the assembly that will weigh approximately 4,500 lbs. before the tool will be self-supported.
2. Pin the center rocker in place beginning with the middle pin.



REV. 6/02  
M4881-66


NOTE: CYLINDER PORTS ON TOP SIDE



- Pin the (2) 4 x 16 Cylinders (5 Shank Rigid and 7 Shank Rigid Models); or (2) 4-1/2 x 16 Cylinders (7 Shank Folding & 9 Shank Folding Models) to the lugs. Loosen the plugs in the cylinder ports to allow the cylinders to be extended.

1-1/4" DIA. x 6-1/4" PIN  
 (4) 1-1/4" SAE FLAT WASHER  
 (2) 1/4" DIA. x 2" ROLL PIN


REV. 9/02  
 M4881-65



M7408-40

- Assemble (4) Tire and Wheel Assemblies to the rocker shaft wheel arms. 5 Shank Rigid and 7 Shank Rigid use 12.5L x 15, 12 Ply Tires on 6-Bolt Rims. 7 Shank Folding Model uses 12.5L x 15 FI Tires on 8-Bolt Rims. 9 Shank Folding Model uses 16.5L x 16 FI Tires on 8-Bolt Rims.  
**Check Tire Inflation:**  
 12.5L x 15, 12-Ply = 52 PSI  
 12.5L x 15, FI = 90 PSI  
 16.5L x 16, FI - 60 PSI  
**Wheel Bolt Torque Values:**  
 6-BOLT = 120 Ft. / Lbs.  
 8-BOLT = 145 Ft. / Lbs.


- Position the TONGUE between the plates at the front of the frame and pin in place.



REV. 6/02  
 M4881-67


6. 5 Shank Rigid and 7 Shank Rigid Models: Install (2) LEVELING LINKS through trunnions on rocker shaft. Trunnion must be rotated to angle the Leveling Link towards the center.  
9 Shank Models: Place 2" BUSHING on the Leveling Link BEFORE installing through the trunnion.

- A.) Place leveling links over ends of pivot weldment, retain with 2" Machine Bushings and 1/2" DIA. x 2-1/2" Roll Pins.  
 B.) Assemble spring, washers, and slotted nut to leveling link. Tighten nut until spring is 10" long.



REV. 6/02  
 M4881-68


7. 7 Shank Rigid Models ONLY: Assemble Frame Ends to center frame.



REV. 6/02  
 M4881-69

8. 5 Shank Rigid, 7 Shank Folding & 9 Shank Folding Models:  
 Bolt (2) Shank Extensions to the center frame as shown.


REV. 6/02  
 M4881-70



## II. WING ASSEMBLY


### 1. 7F & 9F MODEL WING FRAME ASSEMBLY

- A.) Bolt WING FRAMES to Center Frame with (6) Hinge Bolts. Slide Wing Frame rearward and check thrust contact at each hinge. Insert a WEAR WASHER on the thrust side, if clearance allows it.




REV. 6/02  
 M4881-71

- B.) Push the pin and lock through the hinge and special washer until the lock is firmly engaged in the hinge clevis hole.
- C.) Secure the hinge pins with 1-1/2NC Slotted Hex Nuts. After tightening the slotted nut, turn the nut back until a slot in the nut is in alignment with the hole in the hinge pin for the 1/4" DIA. x 3" Cotter Pin.
- D.) Install (2) WING STOPS using 1/2" DIA. U-Bolts and 5/8NC x 1-1/2" GD5 Cap Screws.
- E.) Install WING ROCKERS.



REV. 6/02  
 M4881-72

# WING ROCKER ASSEMBLY- 7 & 9 SHANK FOLDING




Rev. 9/02  
M4881-102

1. Fasten the wing rocker adjustment Eyebolt to the wing frame with 1-1/4NC Hex JAM Nuts. Lock in place with a 3/8" x 1-3/4" Roll Pin. For initial setting there should be 1-1/2" of thread showing.
2. Assemble a 4" x 16" Cylinder to each wing rocker with a (4226-0-4) 1" DIA. x 6-3/8" Pin in the rod end. There are (8) 1" SAE FLat Washers required, (3) on each side of the rod end clevis and (1) on the outside of each rocker lug.
3. Single / Dual Wheels -- Attach the wheel hub assembly to to the wheel arms using 3/4NC x 4" GD5 Bolts, Lock Washers and Hex Nuts.  
Be sure that the yellow patch on the spindle plate is positioned on the bottom.

4. Attach the wing wheels to the wing wheel arms. Torque the wheel bolts to 120 Ft. Lbs.  
**IMPORTANT: CHECK THE HUBS FOR EXCESSIVE END PLAY. IF NECESSARY, ADJUST THE WHEEL HUB AT THIS TIME IN ASSEMBLY.**


DO NOT ALLOW DIRT AND DUST TO ENTER THE HUBS. DIRT IN THE HUBS MAY RESULT IN BEARING FAILURE DURING OPERATION.



## 5. DEPTH CONTROL ASSEMBLY

- A.) Bolt PIVOT ARM WELDMENT to frame with 3/4NC x 3-1/2" GD5 Cap Screw, 1" O.D. x .76" I.D. x 1.19" Long Wear Sleeve, 3/4" STD.. Flat Washer, 3/4" STD. Lock Washer and 3/4NC Hex Nut.

**NOTE: Direction of pivot arm bolt.**





Rev. 12/02  
M48B1-74

B.) Assemble REAR DEPTH LINKAGE to ROCKER WELDMENT and PIVOT ARM WELDMENT.

### III. HYDRAULIC ASSEMBLY


**Caution:** Use only hose that meets or exceeds 3,000 PSI working pressure.

1. 5R & 7R: Install main rocker hydraulics. See illustration on page P28.
2. If optional hydraulic gangs are used, see illustration on page P34.
3. 7F & 9F: Install rocker hydraulics. See illustration on page P30.
4. 7F & 9F: Install wing fold hydraulics. See illustration on page P32.
5. If optional hydraulic gangs are used, see illustration on page P36.




M48B1-80


**Important:** For disc gang hydraulic relief, hydraulic hoses must be installed as shown in illustration to the left. See Disc Gang Hydraulics on pages P34 & P36.




M4881-82



M4881-84



M4881-80



M4881-88

## IV. CHARGING THE CYLINDERS

1. Attach the hydraulic hoses to the tractor. Check the tractor hydraulic reservoir and make sure it is full of the tractor manufacturer's recommended oil.

**Warning:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic lines. Tighten all connections before applying pressure.



Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.


If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result.

When you are sure all connections are tight and leakproof, open the road lock valve and raise the unit. Hold the tractor lever in the raised position to fill each rocker shaft cylinder.

2. Cycle the hydraulic cylinders until all air is purged from the system. When cycling the cylinders, hold the lever for 30 to 45 seconds in the fully raised position to rephase the cylinders.

Continue the cycles until the cylinders respond with immediate solid actuation.

3. When the cylinders are fully extended, install the cylinder locks on the center rocker cylinders.



M4881-75

4. Close the transport lock valve.
5. Remove the stands. The center frame should be free-standing on its own tires.


**Warning:** Have all persons stand clear before removing the frame stands.

## V. DISC GANG ASSEMBLY

**Danger:** Due to their sharpness and weight, serious injury can be inflicted by the disc blades and disc gangs if not handled safely. Keep your co-workers safety in mind. Should personal injury occur, have medical treatment administered immediately.

1. Refer to the placement pages at the back of this manual to help select the correct location for each gang assembly.

2. Roll the FRONT Gangs under the frame with the scrapers on top and to the rear. Raise the disc gang and pin in place with Pin Weldment. Tighten Pin Weldment until slack is removed and lock nut in place with cotter pin. Install all front disc gangs in a similar fashion.




1-1/4NC SLOTTED NUT

1/4 x 2-1/2 COTTER PIN

PIN WELDMENT

M4881-77




M4881-85

### FRONT GANGS

### 7 SHANK RIGID MODEL ONLY

7 Shank Rigid Model: Uses a bolt-on lug at the middle pivot location as shown above.


3. Roll the REAR Gangs under the frame with the scrapers on top and to the rear. Assemble the pivot weldments to the frame but do not tighten. See page P22. Raise the disc gang and pin it in place with the Pin Weldment. Tighten Pin Weldment until slack is removed and lock nut in place with a cotter pin. Install all rear gangs in a similar fashion. Tighten pivot weldment securely and pin nut in place with PTO Lock Pin.



M4881-85

### REAR GANGS



## VI. SUBSOIL SHANK ASSEMBLY



1. Tighten 1" Mounting Bolts to 625 Ft. Lbs.
2. Install SUBSOIL POINTS with 3/8"DIA x 2-1/2" Spiral Expansion Pins.

## VII. LIGHT KIT

Always comply with state and local laws pertaining to lighting. Install the light kit as shown in photos to the right and below.




NOTE: Start by positioning the front 7-pin plug approximately 40" ahead of the hitch pin and then follow the hydraulic hoses to the back of the unit. Make sure that the wires are positioned where they won't be damaged during raising, lowering or folding of the unit.

### VIII. DECALS

It is very important that all decals be placed on the implement. These decals, reflectors, safety and operating messages are just as important as the parts that have been assembled.

Wipe frame members clean before applying decals for better adhesion. If decals or reflectors should become faded or damaged, be sure to replace them.

NOTE: See decal illustration on page P47 of this manual.



**NOTE: PLACE IN SIMILAR LOCATION ON 7R UNIT.**

# MODEL TL3000 5-SHANK

## 1-1/2" TIE RODS

LOCATION	TIE ROD NUMBER	LENGTH
LEFT FRONT	4881-0000-25	70-1/2"
RIGHT FRONT	4881-0000-25	70-1/2"
LEFT REAR	4881-0000-29	73-5/8"
RIGHT REAR	4881-0000-29	73-5/8"

## SCRAPER BARS


LOCATION	SCRAPER TUBE	LENGTH
LEFT FRONT	2008-1-625	62-1/2"
RIGHT FRONT	2008-1-625	62-1/2"
LEFT REAR	2008-1-705	70-1/2"
RIGHT REAR	2008-1-705	70-1/2"

## GANG BEAMS

4881-5035-0	LEFT FRONT GANG BEAM
4881-5034-0	RIGHT FRONT GANG BEAM
4881-5037-0	LEFT REAR GANG BEAM
4881-5036-0	RIGHT REAR GANG BEAM

## DISC BLADES

24" DIAMETER	QTY. - 22
22" DIAMETER	QTY. - 6
20" CUT OUT	QTY. - 2



M4881-34

# MODEL TL3000 7R-SHANK

## 1-1/2" TIE RODS

LOCATION	TIE ROD NUMBER	LENGTH
LEFT FRONT CTR	4881-0000-27	59-1/2"
RIGHT FRONT CTR	4881-0000-27	59-1/2"
LEFT FRONT	4881-0000-30	46-3/8"
RIGHT FRONT	4881-0000-30	46-3/8"
RIGHT REAR	4881-0000-28	107-1/4"
RIGHT REAR	4881-0000-28	107-1/4"

## SCRAPER BARS


LOCATION	SCRAPER TUBE	LENGTH
LEFT FRONT	2008-1-480	48"
RIGHT FRONT	2008-1-480	48"
LEFT REAR	2008-1-1085	108-1/2"
RIGHT REAR	2008-1-1085	108-1/2"

## GANG BEAMS

4881-7135-0	LEFT FRONT GANG BEAM
4881-7134-0	RIGHT FRONT GANG BEAM
4881-7137-0	LEFT REAR GANG BEAM
4881-7136-0	RIGHT REAR GANG BEAM

## DISC BLADES

24" DIAMETER	QTY. - 32
22" DIAMETER	QTY. - 6
20" CUT OUT	QTY. - 2



# MODEL TL3000 7F-SHANK

## 1-1/2" TIE RODS

LOCATION	TIE ROD NUMBER	LENGTH
LEFT FRONT CTR	4881-0000-27	59-1/2"
RIGHT FRONT CTR	4881-0000-27	59-1/2"
LEFT REAR CTR	4881-0000-20	62-5/8"
RIGHT REAR CTR	4881-0000-20	62-5/8"
LEFT FRONT WING	4881-0000-30	46-3/8"
RIGHT FRONT WING	4881-0000-30	46-3/8"
LEFT REAR WING	4881-0000-32	51-3/4"
RIGHT REAR WING	4881-0000-32	51-3/4"

## SCRAPER BARS


LOCATION	SCRAPER TUBE	LENGTH
LEFT FRONT CTR	2008-1-625	62-1/2"
RIGHT FRONT CTR	2008-1-625	62-1/2"
LEFT REAR CTR	2008-1-625	62-1/2"
RIGHT REAR CTR	2008-1-625	62-1/2"
LEFT FRONT WING	2007-1-370	37"
RIGHT FRONT WING	2007-1-370	37"
LEFT REAR WING	2008-1-535	53-1/2"
RIGHT REAR WING	2008-1-535	53-1/2"

## GANG BEAMS

4881-7034-0	LEFT FRONT CTR GANG BEAM
4881-7034-0	RIGHT FRONT CTR GANG BEAM
4881-7037-0	LEFT REAR CTR GANG BEAM
4881-7036-0	RIGHT REAR CTR GANG BEAM
4881-7039-0	LEFT FRONT WING GANG BEAM
4881-7038-0	RIGHT FRONT WING GANG BEAM
4881-7041-0A	LEFT REAR WING GANG BEAM
4881-7040-0A	RIGHT REAR WING GANG BEAM

## DISC BLADES

24" DIAMETER	QTY. - 34
22" DIAMETER	QTY. - 6
20" CUT OUT	QTY. - 2



M4881-36

# MODEL TL3000 9F-SHANK

## 1-1/2" TIE RODS

LOCATION	TIE ROD NUMBER	LENGTH
LEFT FRONT CTR	4881-0000-27	59-1/2"
RIGHT FRONT CTR	4881-0000-27	59-1/2"
LEFT REAR CTR	4881-0000-20	63-5/8"
RIGHT REAR CTR	4881-0000-20	63-5/8"
LEFT FRONT WING	4881-0000-25	72-1/2"
RIGHT FRONT WING	4881-0000-25	72-1/2"
LEFT REAR WING	4881-0000-29	73-5/8"
RIGHT REAR WING	4881-0000-29	73-5/8"

## SCRAPER BARS


LOCATION	SCRAPER TUBE	LENGTH
LEFT FRONT CTR	2008-1-625	62-1/2"
RIGHT FRONT CTR	2008-1-625	62-1/2"
LEFT REAR CTR	2008-1-535	53-1/2"
RIGHT REAR CTR	2008-1-535	53-1/2"
LEFT FRONT WING	2008-1-625	62-1/2"
RIGHT FRONT WING	2008-1-625	62-1/2"
LEFT REAR WING	2008-1-705	70-1/2"
RIGHT REAR WING	2008-1-705	70-1/2"

## GANG BEAMS

4881-7034-0	LEFT FRONT CTR GANG BEAM
4881-7034-0	RIGHT FRONT CTR GANG BEAM
4881-7037-0	LEFT REAR CTR GANG BEAM
4881-7036-0	RIGHT REAR CTR GANG BEAM
4881-9039-0	LEFT FRONT WING GANG BEAM
4881-9038-0	RIGHT FRONT WING GANG BEAM
4881-9041-0	LEFT REAR WING GANG BEAM
4881-9040-0	RIGHT REAR WING GANG BEAM

## DISC BLADES

24" DIAMETER	QTY. - 42
22" DIAMETER	QTY. - 6
20" CUT OUT	QTY. - 2



M4881-37

**This page intentionally left blank.**

# PRODUCTION VARIATION

BOLT VALVE ASSEMBLY TO FRAME USING 4881-5086-0 GUIDE ASSEMBLY.  
 (4881-5086-0 GUIDE ASSEMBLY INCLUDES ITEMS SHOWN AT LEFT.)

